

---

# Luminoscope® PLA 35 - BGA Standard

---

## User manual





---

# Considerations

---

## Copyright and disclaimer

### Copyright

---

No part of this documentation may be reproduced, stored in a retrieval system, or transmitted in any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of LET Automotive NV.

### Disclaimer

---

Every care has been taken by the staff of LET Automotive NV in the compilation of the data contained herein and in the verification of its accuracy when published, however the content of this manual is subject to change without notice due to factors outside the control of LET Automotive NV and this manual should, therefore, be used as a guide only. For example, the products referred to in this publication are continually improved through further research and development and this may lead to information contained in this manual being altered without notice.

This manual is published and distributed on the basis that LET Automotive NV is not responsible for the results of any actions taken by users of information contained in this manual, nor for any error in or omission from this manual. LET Automotive NV does not accept any responsibility whatsoever for misrepresentation by any person whatsoever of the information contained in this manual and expressly disclaims any liability and responsibility, in respect of claims, losses or damage or any other matter, either direct or consequential arising out of or in relation to the use and reliance, upon any information contained or products referred to in this manual.



# Table of Contents

<b>1 Regulations.....</b>	<b>9</b>
1.1 Safety regulations.....	9
1.2 Danger of localized heating.....	9
1.3 Danger laser beam.....	10
1.4 Environmental regulations.....	10
<b>2 Basic Principles.....</b>	<b>11</b>
2.1 Headlamp criteria.....	11
2.2 Adjusting headlamps.....	11
2.3 Lens Principle.....	13
2.4 Advantages of optical block with lens.....	13
2.5 Image processing.....	14
2.6 Alignment with the vehicle.....	16
2.7 Positioning in front of the headlamp.....	17
<b>3 Headlamps.....</b>	<b>19</b>
3.1 ECE or European low beam.....	19
3.2 High beam.....	20
3.3 Fog beam.....	21
3.4 SAE or American low beam.....	22
3.5 Japanese low beam.....	23
3.6 Dynamic headlamps and intelligent lighting systems.....	24
3.6.1 Glare free high beam with beam motorisation.....	24
3.6.2 Glare free high beam with multiple static LED sources.....	25
3.6.3 Dynamic low beam.....	26
<b>4 Prerequisites for checking or adjusting.....</b>	<b>29</b>
4.1 Prerequisites for the vehicle.....	29
4.2 Prerequisites for the headlamps.....	29
4.3 Positioning the system.....	29
<b>5 Technical characteristics.....</b>	<b>31</b>
5.1 PLA 35 models.....	31
5.2 Guiding systems.....	34
5.2.1 PLA 35 DR: double rail.....	35
5.2.2 PLA 35 SR: single rail.....	35
5.2.3 PLA 35 NR: no rail.....	36
5.3 Layout.....	36
5.3.1 Front view.....	37
5.3.2 Top view.....	39
5.3.3 Left side view.....	44
5.3.4 Right side view.....	46
5.3.5 Alignment laser.....	48
5.4 Dimensions.....	50
5.4.1 PLA 35 DR.....	50
5.4.2 PLA 35 SR.....	51
5.4.3 PLA 35 NR.....	52
5.5 Datasheet.....	52

<b>6 Power management.....</b>	<b>55</b>
6.1 Switching the Luminoscope® ON and OFF.....	55
6.2 Power standby.....	56
6.3 Inactivity timer.....	56
6.4 Forced shut down of the Luminoscope®.....	56
<b>7 Operation.....</b>	<b>59</b>
7.1 Test cycle references.....	59
7.1.1 Beam icons.....	59
7.1.2 Left / right vehicle side definition.....	60
7.1.3 Alignment with the vehicle.....	62
7.1.3.1 Alignment mirror.....	62
7.1.3.2 Alignment laser.....	64
7.1.4 Positioning in front of the headlamp.....	65
7.1.5 Mounted height of the headlamp.....	66
7.1.6 ESL - Electronic Spirit Level module.....	69
7.2 Test cycle sequence.....	70
7.2.1 Switching on the Luminoscope®.....	71
7.2.2 Alignment with the vehicle.....	72
7.2.3 Program selection.....	73
7.2.4 Line selection.....	74
7.2.5 Beam selection.....	75
7.2.6 Selection of mounted headlamp height.....	77
7.2.7 Positioning in front of the headlamp.....	77
7.2.8 ESL (Electronic Spirit Level) module compensation.....	79
7.2.9 Beam measurement.....	80
7.2.9.1 Low beam test.....	80
7.2.9.1.1 Aiming mode.....	80
7.2.9.1.2 Audit mode.....	84
7.2.9.2 High beam test.....	88
7.2.9.3 Fog beam test.....	91
7.2.10 Beam measurement results.....	94
7.2.11 Test cycle reports.....	95
7.2.11.1 Test report as a PDF file.....	96
7.2.11.2 Test report as printed ticket.....	97
7.3 OEM test cycle sequences.....	99
7.3.1 ECE-VAR low beam sequence.....	100
7.3.1.1 Summary of the test sequence.....	102
7.3.1.2 Test sequence.....	102
7.3.2 ECE - 15°/45° low beam sequence.....	105
7.3.2.1 Summary of the test sequence.....	107
7.3.2.2 Test sequence.....	107
7.3.3 MDF high beam sequence.....	111
7.3.3.1 Summary of the test sequence.....	113
7.3.3.2 Test sequence.....	113
7.3.4 VOL American low beam sequence.....	118
7.3.4.1 Summary of the test sequence.....	119
7.3.4.2 Test sequence.....	120
7.3.5 VOR American low beam sequence.....	123
7.3.5.1 Summary of the test sequence.....	125
7.3.5.2 Test sequence.....	125
<b>8 Navigation map.....</b>	<b>129</b>
Program selection screen.....	129
System screen.....	129
Setup login screen.....	130
Setup screen.....	130
Computer configuration screen.....	131
Settings program screen.....	131

Verification screen.....	132
Calibration screen.....	132
<b>9 System screen.....</b>	<b>133</b>
9.1 Luminoscope® turn off or restart.....	134
9.2 Language selection.....	136
9.3 System information of the Luminoscope®.....	137
9.4 Reprint last test result.....	139
9.5 Recall recent test results.....	139
9.6 Import / export of data via <i>USB</i> stick.....	141
9.6.1 Export operations: Luminoscope® to <i>USB</i> stick.....	143
9.6.1.1 Export of a configuration file.....	143
9.6.1.2 Export of test result files.....	143
9.6.1.3 Export of log files.....	148
9.6.1.4 Export of a configuration file of vehicles and headlamps.....	152
9.6.2 Import operations: <i>USB</i> to Luminoscope®.....	152
9.6.2.1 Import of a configuration file.....	152
9.6.2.2 Software update from a <i>USB</i> stick.....	152
9.6.2.3 Import of a <i>license token file</i> .....	152
9.6.2.4 Import of a configuration file of vehicles and headlamps.....	153
<b>10 Setup screen.....</b>	<b>155</b>
<b>11 Computer configuration screen.....</b>	<b>161</b>
11.1 Date and time setup.....	163
11.1.1 Manual date and time setting.....	164
11.1.2 Automatic date and time setup.....	165
11.2 <i>Wi-Fi</i> networking.....	166
11.2.1 <i>Wi-Fi</i> applications.....	167
11.2.2 Local Access Point setup.....	168
11.2.3 Regular mode setup.....	169
11.3 <i>Ethernet</i> networking.....	173
11.3.1 <i>Ethernet</i> applications.....	175
11.3.2 <i>Ethernet</i> setup.....	175
<b>12 Remote operation.....</b>	<b>179</b>
12.1 VNC client setup.....	179
12.2 Terminate the session.....	183
<b>13 Web interface.....</b>	<b>185</b>
13.1 Access to the <i>web interface</i> .....	185
13.2 Upload a customer logo for the <i>PDF</i> test reports.....	188
13.3 Check and/or print the <i>PDF</i> test reports.....	189
13.4 Export the configuration file of the Luminoscope®.....	190
13.5 Check and/or modify some settings of the Luminoscope®.....	191
13.6 Check stored info and remotely operate the Luminoscope®.....	193
13.6.1 Access to log files.....	195
13.6.2 Access to camera images.....	196
13.6.3 Access to screenshots.....	197
13.6.4 Access to remote Luminoscope® screen.....	198
<b>14 Personal notes.....</b>	<b>201</b>



---

# 1 Regulations

---

Please read the following regulations before using the system and setting it on a powered status.

## 1.1 Safety regulations

This headlamp tester complies with the necessary safety regulations.

- Improper use or handling of the appliance can compromise the safety of the operator and the environment, as well as the reliability of the measurement.
- Repairs may only be done by the Service engineers of *LET Automotive*. Inexpert repairs can result in danger to the operator and environment.
- Repairs and/or spare parts exchange may only be done with units which are delivered by *LET Automotive*.

Besides the above mentioned safety regulations, the following must also be observed:

- Damaged electrical cables of the appliance or the charging adaptor must immediately be replaced.
- Damaged steel wires on the vertical sliding table must immediately be replaced.
- Only use the supplied 12VDC/60W adaptor to charge the battery of the optical block.
- Only use the supplied 12VDC/60W adaptor to charge the battery of the optional alignment laser.
- Do not put or hang objects on the appliance (tools, clothes, ...).
- Make sure the wheels of the base are always clean. Obstructions on the rails or wheels can bring the system off-balance during a movement.
- The appliance is not water-proof. Keep it safely out from water spills, soaking or submersion into water and any other liquid.
- The appliance is not shock-proof. Protect it against heavy shocks or impacts. Do not drop or let it fall.

## 1.2 Danger of localized heating

### Warning:



- During the seasons of the year when the sun is very low in the sky, there is a risk of the sun shining directly into the collecting lens of the Luminoscope®, so that the focusing effect which is used to complete the headlights tests may cause focalized overheating inside the machine.
- The generated heating may in extreme cases severely damage the Luminoscope®!
- To avoid any possible damage, it is strongly recommended that the dust/sun cover is used whenever the Luminoscope® is not operational.

## 1.3 Danger laser beam

### Green alignment line laser

The headlamp tester may be equipped with an optional green alignment laser with the following characteristics:



**Warning:**

- Laser class 2M, wavelength: 520nm, output power < 5mW
- Staring into the laser can lead to severe damage!
- Do not stare into the laser beam of the laser!



## 1.4 Environmental regulations

**Notice:**



- Be aware of the consequences of incorrect waste disposal.
- Incorrect disposal of recoverable materials may negatively impact the environment.
- When the service life of the Luminoscope® expires, the appliance should not be discarded with normal household waste. It should be offered for recycling according to the local currently valid regulations instead.

The following materials are used for the main parts of the Luminoscope® PLA 35:

Part	Material
Fresnel lens	Polymethyl methacrylate (PMMA)
Stand	Aluminium
Optical block	Polystyrene (PS) with high resistance
Base	Steel
Alignment mirror	Glass with a layer of aluminium
Alignment laser <sup>1</sup>	Steel sheet
Battery in optical block	Nickel-metal-hydride (NiMH) technology based
Battery in alignment laser <sup>1</sup>	Nickel-metal-hydride (NiMH) technology based

<sup>1</sup> Part availability depends on the customer specific configuration of the Luminoscope® PLA 35.

---

## 2 Basic Principles

---

What follows is a general explanation of the principles involved in the design and use of Luminoscope® devices and their environment.

### 2.1 Headlamp criteria

During an international conference in Vienna in 1958 was agreed that the headlamps on vehicles should comply with the following criteria:

- A high beam should illuminate the road in front of the vehicle for at least 100m (300ft).
- A low beam should illuminate the road in front of the vehicle for at least 40m (120ft) without blinding the oncoming vehicles.




Figure 1: Headlamp criteria

These fundamental criteria don't describe the intensity values, any measuring procedure or how to prevent blinding the oncoming traffic. Therefore, different countries have developed their own standards and technical requirements.

The definition of a headlamp is determined by those standards. In Europe for instance the low beam is described by a "cut off" line which distributes the light beam in a sharp divided light and dark zone, while a low beam in America has to have minimal and maximal intensities in a number of predefined points.

### 2.2 Adjusting headlamps

The beam from a headlamp is normally directed towards the ground ahead of the vehicle for a low beam (approximately 40m), and straight ahead for a high beam (approximately 100m).

In order to better determine beam orientation, a perpendicular screen is placed in front of the vehicle at a somewhat shorter distance (a minimum of 10m). On this screen, at the same height, and relative to the vehicle axis, the position of the headlamps are indicated.

The lamps can thus be adjusted and checked, taking in account the required inclination settings.




Figure 2: Basic principle of headlamp aiming on a 10m wall

If a white screen is placed at a distance of 10m in front of the headlamp, the inclination angle (slope) of the headlamp under test can be determined and expressed in *cm/10m* or *%*. This kind of projection screen is also called a *10m wall*.

**L** is the distance between the headlamp and the projection screen and is equal to 10m. The horizontal blue dotted line in the image below indicates the *mounting height* of the headlamp. This height should be marked on the 10m wall. The sloped dotted line represents the beam projection of the *cut-off line* of the low beam. The inclination angle (slope) of the headlamp is indicated as  $\alpha$  and can be expressed in degrees.

**H** represents the distance between the *mounting height* of the headlamp and the beam projection of the *cutoff line*, measured on the 10m wall. If  $L=10\text{m}$  and  $H=10\text{cm}$ , the headlamp inclination is equal to  $10\text{cm}/10\text{m}$ , or 1%.




Figure 3: Beam slope

The following table provides the eventually needed conversion between the different units.

cm/10m	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
%	1.5	1.4	1.3	1.2	1.1	1	0.9	0.8	0.7	0.6	0.5	0.4	0.3	0.2	0.1	0
inch/25feet	4.5	4	3.5	3	2.5	2	1.5	1	0.5	0						
degrees		0.8			0.6			0.4			0.2					0

Figure 4: Unit conversion

This method has some disadvantages:

- It requires an indoor open area, over 10 meters long.
- The illumination level of that area has to be constant, mainly dimmed and independent from the varying conditions of natural light.
- The axes must be meticulously specified for each and every different vehicle and for any new vehicle alignment process.
- The method is purely visual and highly dependent on the operator skills and interpretation.

## 2.3 Lens Principle

The use of a converging lens placed at the focal length reduces the distance to the screen dramatically and eliminates the need of a dark room.




Figure 5: Parallel light rays entering the lens

All parallel rays from the same direction are concentrated in one point on the white projection screen inside the Luminoscope®.




Figure 6: Parallel light rays from different angles entering the lens

Every point on the screen represents a collection of rays from the same direction.

## 2.4 Advantages of optical block with lens

The use of a collecting lens has advantages over the 10m wall projection method.

- The distance to the screen is dramatically reduced: from 10m to 0.5m.
- The beam intensity is much higher, dimming or cancelling the ambient light is no longer necessary.
- The white projection screen is positioned at the focal distance of the lens. All parallel rays from the same direction are concentrated in one point. Consequently, the relative position of the system in relationship to the lamp becomes less important as the beam projection of the screen remains identical, independent of the place where the rays enter the lens.

Actually, each point on the screen is thus representing the light emitted in the corresponding direction. This is the *candela meter principle*. The luminance  $E$  of a point on the screen (in lumen/meter<sup>2</sup> = Lux, or lumen/foot<sup>2</sup> = foot candle) represents the luminous intensity  $I$  (in lumen/steradian = candela) of the source in the corresponding direction.

It can be mathematically demonstrated that  $I = F^2 \times E$ , where  $F$  is the focal length of the lens.

Luminous intensity measurements in candela can thus easily be made. The result is the same, regardless of the place where the rays enter the lens, at the top or at the bottom.

Care should be taken, nevertheless, to capture a maximum of the light from the beam, since any light from the beam not entering the Luminoscope® will not be available for measurements and pattern building. To achieve it, the Luminoscope® is equipped with an electronic *Position Check* system which continuously monitors the position in front of the headlamp and guides the operator to determine the ideal position of the optical block lens in front of the headlamp.

## 2.5 Image processing

A CMOS camera points to the internal white projection screen and acquires the reflected image for further process.




Figure 7: CMOS camera pointing at white projection screen

The horizontal and vertical lamp projection range is  $\pm 100\text{cm}/10\text{m}$ .




Figure 8: Projection screen with areas identification

1	Projection screen area		2	Camera viewing area	
3	Lamp testing area		4	Absolute zero reference	
5	Horizontal projection screen range		6	Vertical projection screen range	
7	Horizontal viewing range	340cm/10m	8	Vertical viewing range	270cm/10m
9	Horizontal lamp testing range	200cm/10m	10	Vertical lamp testing range	200cm/10m
11	Leftwards testing range	-100cm/10m	12	Rightwards testing range	+100cm/10m
13	Upwards testing range	+100cm/10m	14	Downwards testing range	-100cm/10m


The shutter setting of the camera is automatically controlled to provide an unclipped image under any circumstance. This allows absolute intensity measurements in kCd.

Camera data is analyzed by powerful algorithms to determine the position of the beam and to obtain other relevant data.

## 2.6 Alignment with the vehicle

In order to obtain a reliable measurement of the headlamp, it is necessary to achieve a good alignment of the Luminoscope® with the slope of the vehicle standing area and the longitudinal axis of the vehicle.

### In the horizontal plane



*Figure 9: Horizontal plane alignment*

The easiest way to achieve a good horizontal alignment with the vehicle is to place the vehicle on a horizontal floor and set the optical block also horizontal with the aid of the spirit level. In practice not so many floors are perfectly horizontal. There are two practical methods to achieve it:

- Measure the floor slope (check corresponding manual) and tilt the optical block in the same direction with the same slope.
- Measure the floor slope and add or subtract that value (depending on the direction of the floor slope) to the computed value of the beam position by the optical block.

### In the vertical plane




Figure 10: Vertical plane alignment

The precision of the measurement of the L/R position of the beam depends mainly on the vertical alignment of the vehicle towards the optical block. As an example, a simple misalignment of 5mm on a wheelbase of 2m will give an error of  $5 \times 5\text{mm} = 2.5\text{cm}/10\text{m}$  in the L/R measurement of the beam.

The vertical plane is also called the *longitudinal direction* of the vehicle.

In order to help the operator to correctly align the Luminoscope® with the longitudinal axis of the vehicle, the system is equipped with an alignment mirror, and optionally with an alignment laser. The reference lines on the mirror, as well as the optional laser line, should be calibrated perpendicular with the optical axis of the headlamp tester.

The operator rotates the stand, looking for the intersection point of the reference line(s), either those on the mirror or the laser projection, with two symmetrical points on the vehicle which are also considered as perpendicular with the longitudinal axis of the vehicle.


This procedure ensures the longitudinal alignment between the Luminoscope® and the vehicle longitudinal axis.

## 2.7 Positioning in front of the headlamp

It is of great importance that the lens of the Luminoscope® is correctly positioned in front of the headlamp to ensure that as many light rays as possible enter the lens.

This guarantees that the beam image is displayed realistically on the white projection screen inside the Luminoscope® to be able to perform a correct headlamp measurement.

With this purpose, the Luminoscope® system is provided with the electronic *Position Check* system that uses twelve photocells around the lens 1.



*Figure 11: Position Check cells around the lens*

---

# 3 Headlamps

---

This is a review of the illumination patterns that different headlamps produce.

## 3.1 ECE or European low beam

**Note:** The terms *low beam* and *dipped beam* also refer to the same type of headlamp and are used interchangeably.

The purpose of the low beam is to illuminate the road ahead of the vehicle and traffic signs up to a distance of approximately 40m without blinding oncoming traffic. The asymmetrical low beam must be adjusted on a predefined inclination value. In Europe e.g. it's an inclination between -1% (or -10cm/10m) and -1.5% (or -15cm/10m). The reference point of the beam is the intersection of the horizontal part with the sloped part and is referred to as *V-point*. It is also called *kink point* and *elbow point*.

There exist two types of ECE low beams, depending on which side of the road the vehicle is driving:

### LHD (Left Hand Drive)

---

The steering wheel is positioned on the left side of the vehicle and the driver uses the right side of the road. Some examples of countries on which this driving type is implemented include (but are not limited to) Belgium, France and Germany, among many others.




Figure 12: Low beam LHD

### RHD (Right Hand Drive)

---

The steering wheel is positioned on the right side of the vehicle and the driver uses the left side of the road. Some examples of countries on which this driving type is implemented include Great Britain, Ireland, Japan, Thailand, Malaysia, Indonesia, New Zealand, Australia, India, South Africa, among many others.



Figure 13: Low beam RHD

The world map below shows the implemented driving types for each country.




Figure 14: Implementation of LHD and RHD driving types across the world

## 3.2 High beam

**Note:** The terms *high beam* and *main beam* refer to the same type of headlamp and are used interchangeably.

The purpose of the high beam is to illuminate the road ahead of the vehicle at a further distance of approximately 100m. The form of the beam is rather oval. The reference point is the point with the highest intensity (hotspot).

There are two different ways of construction:

- The high beam is integrated in the same housing of the low beam. So it is not possible to separately adjust high and low beam. In most countries, the low beam is adjusted because this is the driving beam. Due to the construction of the headlamp, the high beam will be at an inclination value that is  $1\pm\%$  or  $10\pm\text{cm}/10\text{m}$  higher than the low beam value.
- The high beam is a standalone headlamp so both beams can be separately adjusted with their own adjusting screws. Adjustment of the high beam is done at a value of  $1\pm\%$  or  $10\pm\text{cm}/10\text{m}$  higher than the low beam value.



Figure 15: High beam

### 3.3 Fog beam

Fog beams are mounted at the front bottom of the vehicle and illuminate the road as far as possible under fog, heavy rain or snow conditions.

The form of the beam is a broad band of light, where the reference is the flat horizontal top line (*cut-off line*) which is normally adjusted at 1 % or 10 cm/10m below the low beam value. A fog beam only has one adjusting screw controlling the inclination.




Figure 16: Fog beam

### 3.4 SAE or American low beam

**Note:** The terms *low beam* and *dipped beam* also refer to the same type of headlamp and are used interchangeably.

SAE (Society of Automotive Engineers)/ American low beams have an LHD shaped *cut-off line* with a small step and a zone of high intensity (*hotspot*) on the right side of the small step.

American low beams must be aimed – according to the marking on the glass – referring to the left or right side of the *cut-off line*.

There are two types of American low beams, requiring different adjustment methods:

**VOL - Visually Optical Left**

The left part of the *cut-off line* should be aimed at an inclination of -0,7 %.

**VOR - Visually Optical Right**

The right part of the *cut-off line* should be aimed at an inclination of 0 %.




Figure 17: SAE low beam VOL or VOR

### 3.5 Japanese low beam

**Note:** The terms *low beam* and *dipped beam* also refer to the same type of headlamp and are used interchangeably.

The Japanese low beam has some similarities with a mirrored image of the SAE low beam, because the Japanese driver uses the left side of the road (RHD). However there are subtle details regarding the different heights of the zones at both sides of the step which make them different.




Figure 18: Japanese low beam

### 3.6 Dynamic headlamps and intelligent lighting systems

In order to improve road safety, sophisticated technologies are introduced to make lighting systems more intelligent.

These new technologies include *adaptive front lighting*, *variable intelligent lighting*, *dynamic bending lights*, *dynamic light spots*, *glare free high beam*, etc.

Most of these headlamps are controlled by other electronic systems of the car, such as intelligent cameras, radars, steering angle detection, etc. These kind of headlamps need special adjustment sequences and mostly require a calibration set-up of the vehicle (through vehicle specific diagnosis link). The calibration values should be stored afterwards in the electronic control unit (*ECU*) of the vehicle.

#### 3.6.1 Glare free high beam with beam motorisation

**Note:** The terms *high beam* and *main beam* refer to the same type of headlamp and are used interchangeably.

An intelligent camera, fitted behind the windscreen, detects both vehicles in front of the car and oncoming vehicles. The high beam zone that might cause glare is darkened by adjusting the light image (by means of a servomotor). The beam images underneath can be moved horizontally in order to avoid glare at one specific zone on the road.




Figure 19: Left glare free high beam




Figure 20: Right glare free high beam

An example of this headlamp principle is the *MDF (Maskiertes Dauerfernlicht)* high beam.

### 3.6.2 Glare free high beam with multiple static LED sources

An intelligent camera, fitted behind the windscreen, detects both vehicles in front of the vehicle and oncoming vehicles. The high beam zones that might cause glare are darkened by dimming or switching off one or more *LED* sources. So the overall high beam image is electronically controlled in order to avoid glare at multiple zones on the road.



Figure 21: Matrix high beam simulation scene

Calibrating a *Matrix* high beam with a headlight tester requires in most cases a calibration set-up of the vehicle (through vehicle specific diagnosis link) to switch on one of the *LED* sources as a reference.

The horizontal position of the reference spot should be mechanically adjusted or in other cases its position should be measured. The position is stored afterwards in the electronic control unit (*ECU*) of the vehicle.




Figure 22: Reference spot of matrix high beam


An example of this headlamp principle is the *Matrix* high beam.

#### 3.6.3 Dynamic low beam

**Note:** The terms *low beam* and *dipped beam* also refer to the same type of headlamp and are used interchangeably.

With a dynamic low beam, the horizontal position of the beam can be controlled by the steering angle, to achieve the most optimal light distribution on the road in all conditions (e.g. when the vehicle takes a turn). There are different technologies available for this purpose.

By means of a servo motor the horizontal *cut-off line* position could be automatically adapted during driving. In addition, there are also systems available with multiple *LED* sources as in the image underneath. It shows an LHD low beam *cut-off line* with a step of 90°. The upper part of the *cut-off line* (horizontal bar with the highest intensity at the right side of the image) can be made wider or smaller, depending on the steering angle of the vehicle. This is done by controlling the *LED* sources in order to have the most optimal road illumination for all steering angles when driving in low beam mode.



*Figure 23: Dynamic low beam projection*



---

# 4 Prerequisites for checking or adjusting

---

In order to achieve an accurate and stable headlamp measurement or adjustment, a number of prerequisites must be taken care of.

## 4.1 Prerequisites for the vehicle

- The front wheels must be in the straight-line travel position.
- The tires should be inflated to manufacturer specified pressures.
- The vehicle should be empty, with the hand-brake released.
- The springs and the shock-absorbers should be in their equilibrium positions. For vehicles with hydro-pneumatic suspension, the motor should be running.
- Where the vehicle is equipped with a manual control to adjust the low beam, it should be checked that it is in its rest position.

## 4.2 Prerequisites for the headlamps

- Check that the headlamps are rigidly connected to the vehicle.
- Check whether the two lamp glasses are identical, whether they are in their correct angular position and that they are not cracked.
- Check that the lamp glasses are clean and whether the reflectors are in a satisfactory state.
- Check that the headlamp units neither contain any water, or are misted up.

## 4.3 Positioning the system

- Locate the vehicle approximately 20-60 cm from the lens of the headlamp tester.
- Check regularly that the air bubble in the spirit level is centered at the lamps' test place.



---

# 5 Technical characteristics

---

## 5.1 PLA 35 models

Depending on the provided guiding system, there are different Luminoscope® models available.

Model	Height range of the Luminoscope optical axis	Description
<b>Luminoscope® PLA 35 DR</b>	Between 215 mm and 1330 mm. Range might extend slightly further.	The two V-shaped front wheels of the trolley base are guided on a hexagonal rail. The simple flat wheel runs on the square rail. The uniform levelling of the rails can be easily adjusted to obtain a perfect horizontal movement over the whole length of the rails.
<b>Luminoscope® PLA 35 SR</b>	Between 235 mm and 1350 mm. Range might extend slightly further.	<p>The two rubber front wheels of the trolley are guided on a simple M-shaped steel rail, attached to the floor. The rubber rear wheel runs on the floor. There is no adjustment mechanism provided to adjust the uniform levelling of the rail.</p> <p>The inclination of the optical unit will subtly vary without any doubt while displacing the Luminoscope® and this has a direct consequence on the headlamp measurement. To solve this problem, the Luminoscope® PLA 35 SR is equipped with the <i>ESL</i> (Electronic Spirit Level) module.</p>
<b>Luminoscope® PLA 35 NR</b>	Between 230 mm and 1360 mm. Range might extend slightly further.	<p>The three rubber wheels of the trolley base run on the floor. The Luminoscope® can be used on different locations which have identical floor slope for the vehicle standing area.</p> <p>The inclination of the optical unit will subtly vary without any doubt while displacing the Luminoscope® and this has a direct consequence on the headlamp measurement. To solve this problem, the Luminoscope® PLA 35 NR is equipped with the <i>ESL</i> (Electronic Spirit Level) module.</p>

### Luminoscope® PLA 35 DR

---



Figure 24: General view of Double Rail model (PLA 35 DR)

**Luminoscope® PLA 35 SR**

Figure 25: General view of Single Rail model (PLA 35 SR)

**Luminoscope® PLA 35 NR**

Figure 26: General view of No Rail model (PLA 35 NR)

## 5.2 Guiding systems

The two front wheels of the trolley base of the Luminoscope® PLA 35 can be guided on one non-adjustable rail profile that is fixed to the floor. Other systems are guided on two robust adjustable rails which are fixed to the floor or recessed in the floor.

Guiding the Luminoscope® PLA 35 on rails ensures an easier alignment of the Luminoscope® with the vehicle. In case the rails are adjustable, the Luminoscope® remains horizontally along the whole range of the rails.

Luminoscope® PLA 35 systems without guiding rails are also available. In this case, the rubber wheels of the trolley base are just running on the floor. The equipment can be used on different locations which have the same floor slope for the vehicle standing area.

On systems with non-adjustable rails or without any rails, the inclination of the optical block will subtly vary without any doubt while displacing the system. This has a direct consequence on the measurement results of the Luminoscope®. To solve this problem, the Luminoscope® PLA 35 could be equipped with an *ESL* (Electronic Spirit Level) module.

The purpose of the *ESL* (Electronic Spirit Level) module is to automatically take into account a possible inclination of the optical block (caused for instance by the slope of non-adjustable rails or the absence of any guiding rail) to ensure an accurate measurement.

There are three different guiding systems available, depending on the use or type of rail:

- DR – Double Rail
- SR – Single Rail
- NR – No Rail

### 5.2.1 PLA 35 DR: double rail

The two V-shaped front wheels 1 of the trolley base are guided on a hexagonal rail 2. The simple flat rear wheel 3 runs on the square rail 4. The uniform levelling of the rails can be easily adjusted to obtain a perfect horizontal movement of the Luminoscope® over the whole length of the rails.




Figure 27: Double rail (DR)

### 5.2.2 PLA 35 SR: single rail

The two front rubber wheels 1 of the trolley base are guided on a simple M-shaped steel rail 2, fixated to the floor. The rear rubber wheel 3 runs on the floor.




Figure 28: Single rail (SR)

There is no adjusting mechanism provided to adjust the uniform levelling of the rail.

### 5.2.3 PLA 35 NR: no rail

The three rubber wheels of the trolley base run on the floor.




Figure 29: No rail (NR)

The system can be used on different locations which have an identical floor slope for the vehicle standing area.

The shape of the NR trolley differs from that for DR and SR models. The reason behind this is achieving an easier movement of the system between locations.

## 5.3 Layout

The following sections include detailed graphics and callouts of the Luminoscope® which lead to an easier identification of the different parts and models.



**Remember:** Depending on the ordered options, the supplied unit may look slightly different from the following drawings.

### 5.3.1 Front view




Figure 30: Front view of the Luminoscope®

1	Stand	The optical block is attached to the vertical sliding table of the stand.
2	Alignment mirror	Used to align the optical axis of the optical block with the longitudinal axis of the vehicle.
3	Green alignment laser (optional)	Used to align the optical axis of the optical block with the longitudinal axis of the vehicle.
4	Mirror / laser handle (standard type)	Used to tilt the alignment mirror / laser assembly.

5	Mirror / laser lever (optional)	Used to tilt the alignment mirror / laser assembly. The button on the lever extends the power-on button on the alignment laser.
6	Counterweight cable	Connects the vertical sliding table of the optical block with the counterweight inside the stand.
7	Optical block	The optical block includes a lens, a white projection screen, a digital camera, a control panel and a connector plate. Captures, processes and analyzes the headlight beam projection.
8	Red laser pointer (optional)	Its purpose is to point at the lowest rim of the reflector of the headlamp to determine the mounting height of the headlamp. Only applicable in certain countries.
9	Trolley base	The trolley base on wheels ensures the stability and the perpendicularity of the system.
10	V-wheel with eccentric axle	Front wheel guides the system on the hexagonal rail. Provided with an eccentric axis which allows for the vertical adjustment of the stand.
11	Flat wheel with eccentric axle	Flat wheel running on the square rail. Provided with an eccentric axis which allows for the vertical adjustment of the stand.
12	Rubber wheel with eccentric axle	The rubber wheel runs on a non-adjustable rail profile. Provided with an eccentric axis which allows for the vertical adjustment of the stand.
13	Rubber wheel	The rubber wheel runs on a non-adjustable rail profile.
14	Rubber wheel with eccentric axle	The rubber wheel runs on the floor. Provided with an eccentric axis which allows for the vertical adjustment of the stand.
15	V-wheel	Front wheel of the system running on the hexagonal rail.

### 5.3.2 Top view

#### PLA 35 DR




Figure 31: Top view Luminoscope® PLA 35 DR

1	Alignment mirror	Used to align the optical axis of the optical block with the longitudinal axis of the vehicle.
2	Green alignment laser (optional)	Used to align the optical axis of the optical block with the longitudinal axis of the vehicle.
3	Mirror / laser lever (optional)	Used to tilt the alignment mirror / laser assembly. The button on the lever extends the power-on button on the alignment laser.
4	Connector for external power-on button of alignment laser	Connected to the button of the optional lever, when this is supplied.
5	Optical block	The optical block includes a lens, a white projection screen, a digital camera, a control panel and a connector plate. Captures, processes and analyzes the headlight beam projection.
6	Control panel	Control panel with 7" colour touch screen to operate the system and to visualize the headlight image.
7	Reference spirit level	The reference spirit level is used as a tool to verify the calibration status of the optical block. The Luminoscope® is initially calibrated at the factory to a point on which the optical axis of the optical block is horizontal.

8	Perspex window	The headlight image on the projection screen inside the optical block is visible through this window.
9	Handle	Handle on the vertical sliding table to move the system and vertically displace the optical block.
10	Trolley base	The trolley base on wheels ensures the stability and the perpendicularity of the system.
11	V-wheel with eccentric axle	Front wheel guides the system on the hexagonal rail. Provided with an eccentric axis which allows for the vertical adjustment of the stand.
12	Adjustable hexagonal rail profile	Adjustable rail profile embedded in the floor, which guides the two front V-wheels of the trolley base.
13	Flat wheel with eccentric axle	Flat wheel running on the square rail. Provided with an eccentric axis which allows for the vertical adjustment of the stand.
14	Adjustable square rail profile	Adjustable square rail profile embedded in the floor, over which the rear flat wheels of the trolley base runs.


**PLA 35 SR**

Figure 32: Top view Luminoscope® PLA 35 SR

1	Alignment mirror	Used to align the optical axis of the optical block with the longitudinal axis of the vehicle.
2	Green alignment laser (optional)	Used to align the optical axis of the optical block with the longitudinal axis of the vehicle.

3	Mirror / laser lever (optional)	Used to tilt the alignment mirror / laser assembly. The button on the lever extends the power-on button on the alignment laser.
4	Connector for external power-on button of alignment laser	Connected to the button of the optional lever, when this is supplied.
5	Optical block	The optical block includes a lens, a white projection screen, a digital camera, a control panel and a connector plate. Captures, processes and analyzes the headlight beam projection.
6	Control panel	Control panel with 7" colour touch screen to operate the system and to visualize the headlight image.
7	Reference spirit level	The reference spirit level is used as a tool to verify the calibration status of the optical block. The Luminoscope® is initially calibrated at the factory to a point on which the optical axis of the optical block is horizontal.
8	Perspex window	The headlight image on the projection screen inside the optical block is visible through this window.
9	Handle	Handle on the vertical sliding table to move the system and vertically displace the optical block.
10	Trolley base	The trolley base on wheels ensures the stability and the perpendicularity of the system.
11	Rubber wheel with eccentric axle	The rubber wheel runs on a non-adjustable rail profile. Provided with an eccentric axis which allows for the vertical adjustment of the stand.
12	Non-adjustable rail profile	Non-adjustable rail profile mounted on the floor. The two front rubber wheels of the trolley base are guided on the rail.
13	Rubber wheel with eccentric axle	The rubber wheel runs on the floor. Provided with an eccentric axis which allows for the vertical adjustment of the stand.

## PLA 35 NR





Figure 33: Top view Luminoscope® PLA 35 NR

1	Alignment mirror	Used to align the optical axis of the optical block with the longitudinal axis of the vehicle.
2	Green alignment laser (optional)	Used to align the optical axis of the optical block with the longitudinal axis of the vehicle.
3	Mirror / laser lever (optional)	Used to tilt the alignment mirror / laser assembly. The button on the lever extends the power-on button on the alignment laser.
4	Connector for external power-on button of alignment laser	Connected to the button of the optional lever, when this is supplied.
5	Optical block	The optical block includes a lens, a white projection screen, a digital camera, a control panel and a connector plate. Captures, processes and analyzes the headlight beam projection.
6	Control panel	Control panel with 7" colour touch screen to operate the system and to visualize the headlight image.
7	Reference spirit level	The reference spirit level is used as a tool to verify the calibration status of the optical block. The Luminoscope® is initially calibrated at the factory to a point on which the optical axis of the optical block is horizontal.
8	Perspex window	The headlight image on the projection screen inside the optical block is visible through this window.

9	Handle	Handle on the vertical sliding table to move the system and vertically displace the optical block.
10	Trolley base	The trolley base on wheels ensures the stability and the perpendicularity of the system.
11	Rubber wheel with eccentric axle	The rubber wheel runs on the floor. Provided with an eccentric axis which allows for the vertical adjustment of the stand.
12	Rubber wheel	The rubber wheel runs on the floor.

5.3.3 Left side view



1	Stand	The optical block is attached to the vertical sliding table of the stand.
---	-------	---

2	Green alignment laser (optional)	Used to align the optical axis of the optical block with the longitudinal axis of the vehicle.
3	Alignment mirror	Used to align the optical axis of the optical block with the longitudinal axis of the vehicle.
4	Mirror / laser lever (optional)	Used to tilt the alignment mirror / laser assembly. The button on the lever extends the power-on button on the alignment laser.
5	Optical block	The optical block includes a lens, a white projection screen, a digital camera, a control panel and a connector plate. Captures, processes and analyzes the headlight beam projection.
6	Vertical sliding table	The sliding table carries the optical block and can be displaced vertically by means of 3 small guiding wheels on the stand.
7	Fixation screws for optical block	The optical block is attached to the vertical sliding table by means of 4 screws DIN912 M6x20mm and 4 copper washers.
8	Handle	Handle on the vertical sliding table to move the system and vertically displace the optical block.
9	Trolley base	The trolley base on wheels ensures the stability and the perpendicularity of the system.
10	V-wheel with eccentric axle	Front wheel guides the system on the hexagonal rail. Provided with an eccentric axis which allows for the vertical adjustment of the stand.
11	Flat wheel with eccentric axle	Flat wheel running on the square rail. Provided with an eccentric axis which allows for the vertical adjustment of the stand.
12	Rubber wheel with eccentric axle	The rubber wheel runs on a non-adjustable rail profile. Provided with an eccentric axis which allows for the vertical adjustment of the stand.
13	Rubber wheel with eccentric axle	The rubber wheel runs on the floor. Provided with an eccentric axis which allows for the vertical adjustment of the stand.
14	Rubber wheel with eccentric axle	The rubber wheel runs on the floor. Provided with an eccentric axis which allows for the vertical adjustment of the stand.
15	Rubber wheel	The rubber wheel runs on the floor.
16	Connectors plate	Provides all the power and signal connectors of the optical block. There are different available configurations. Shown are <i>Full option</i> (A) and <i>Standard model</i> (B).
17	Power button with control light	Switches the optical block ON and OFF. Press the button 1 second to switch on the system or to recover from stand-by mode. Press the button 4 seconds to reset the system (cold start). The control light blinks to indicate the charging status of the battery.
18	12VDC charging connector	The internal battery pack of the optical block can be charged with the supplied 12VDC/60W adaptor.
19	USB connector	Multipurpose USB port: system backup and upgrade, USB keyboard or USB barcode scanner.

20	RS232 connector	Serial line for communication purposes.
21	HDMI connector (optional)	Signal output connector for optional HDMI monitor attached to the stand.
22	12VDC power connector for HD-MI monitor (optional)	Power for optional HDMI monitor attached to the stand.

### 5.3.4 Right side view




Figure 35: Right view Luminoscope® PLA 35

1	Stand	The optical block is attached to the vertical sliding table of the stand.
2	Alignment mirror	Used to align the optical axis of the optical block with the longitudinal axis of the vehicle.
3	Green alignment laser (optional)	Used to align the optical axis of the optical block with the longitudinal axis of the vehicle.
4	Mirror / laser lever (optional)	Used to tilt the alignment mirror / laser assembly. The button on the lever extends the power-on button on the alignment laser.
5	Counterweight cable	Connects the vertical sliding table of the optical block with the counterweight inside the stand.
6	Upper mechanical stop	Stops the vertical displacement of the sliding table in the highest position.
7	Lower mechanical stop	Stops the vertical displacement of the sliding table in the lowest position.
8	Headlamp mounting height indication sticker	Sticker with the different height zones. The specific sticker model, and even its requirement, depends on local authorities and norms. Please read the specific chapter on this topic if available.
9	Headlamp mounting height indicator	Shows the height zone in which the optical block is located after a correct light positioning with the help of the <i>Position Check</i> arrows.

### 5.3.5 Alignment laser




Figure 36: Alignment laser and mirror assembly

1	Alignment mirror	Used to align the optical axis of the optical block with the longitudinal axis of the vehicle.
2	Green alignment laser (optional)	Used to align the optical axis of the optical block with the longitudinal axis of the vehicle.
3	Auto power-off time adjustment	Trimmer for adjusting the activation time for the alignment laser auto power-off function, between 6 sec and 2 minutes.
4	Power-on button	Push the button to turn on the alignment laser. The laser turns off automatically after a pre-set time.
5	12VDC charging connector	Battery charging connector. The internal battery pack provides power to the alignment laser. Use only the supplied 12VDC/60W adaptor.

6	Status LED	This bicolor LED is connected to a voltage monitor that measures the battery voltage during charging and normal user. The color of the LED indicates the current status. Refer to the table below for a complete explanation.
7	Connector for external power-on button of alignment laser	Connected to the button of the optional lever, when this is supplied.
8	Power-on button on lever	Push the button to turn on the alignment laser. The laser turns off automatically after a pre-set time.
9	Mirror / laser lever (optional)	Used to tilt the alignment mirror / laser assembly. The button on the lever extends the power-on button on the alignment laser.

The color of the status LED 6 varies with the battery charge or usage cycle as follows:

While charging	RED	Charging voltage too low.
	ORANGE	Battery is being charged.
	GREEN	Battery fully charged.
While in use	RED	Battery voltage too low.
	ORANGE	Battery voltage is still enough.
	GREEN	Battery voltage OK.

## 5.4 Dimensions

### 5.4.1 PLA 35 DR




Figure 37: PLA 35 DR: front and top views

## 5.4.2 PLA 35 SR




Figure 38: PLA 35 SR: front and top views

5.4.3 PLA 35 NR




Figure 39: PLA 35 NR: front and top views

5.5 Datasheet

Models	Luminoscope® PLA 35 DR		Double Rail
	Luminoscope® PLA 35 SR		Single Rail
	Luminoscope® PLA 35 NR		No Rail
Headlamp assessment type	Digital (CMOS camera)		
Testing range	Up	0 - 10	%
	Down	0 - 10	%
	Left	0 - 10	%
	Right	0 - 10	%
	Luminous intensity	0 - 125	kCd
Measurement tolerance	±1 cm/10m		

		±0,1	%
Measurement resolution		1	mm/10m
		0,01	%
Measuring distance between headlamp and Luminoscope® lens		200 - 600	mm
Vertical positioning range, measured from lens center to ground	PLA 35 DR	215 - 1330	mm
	PLA 35 SR	235 - 1350	mm
	PLA 35 NR	230 - 1360	mm
Track distance	PLA 35 DR	560	mm
Device for horizontal alignment	Alignment mirror on top of the stand		
	Alignment laser on top of the stand (optional)		
Device for vertical alignment	ESL (Electronic Spirit Level) module - only for certain models		
Measuring range for ESL (Electronic Spirit Level) module	Pitch and roll angle	±2	%
Dimensions (Height / Width / Depth)	PLA 35 DR	1843 / 696 / 674	mm
	PLA 35 SR	1849 / 696 / 705	mm
	PLA 35 NR	1848 / 620 / 665	mm
Weight		≈ 50	kg
Operating temperature range		-10 to +35	°C
Relative humidity		< 80	%
Optical block internal battery	Technology	NiMH	
	Voltage	7,2	VDC
	Capacity	9	Ah
	Continuous operating time	8	h
	Charger voltage	12	VDC
	Charger power	60	W
	Charging cycle	12	h
Optional Alignment laser battery	Technology	NiMH	
	Voltage	4,8	VDC
	Capacity	1,9	Ah
	Continuous operating time	6	h
	Charger voltage	12	VDC
	Charger power	60	W
	Charging cycle	10	h
Color LCD touch screen	Size	7	Inch
	Resolution	1024 x 600	px
Interfaces	LAN	1	Gbps
	WLAN	WPA2 / 802.11bgn	
	Bluetooth	v4.0	
	Serial	RS232	
	HDMI (optional)	1280 x 720	px
	USB	v2	




# 6 Power management

This chapter explains the details on the power-on and off cycle, showing how to switch the Luminoscope® on for normal use and how to switch it off when required.

It also explains the *standby mode* and how to wake the system up after inactivity.

Finally the *auto power-off* feature and the *system reset* are explained.

## 6.1 Switching the Luminoscope® ON and OFF



## 6.2 Power standby

	10	Standby timer	When the Luminoscope® is turned on but not used for a while (no button pressed, no lamp measured, etc), it will switch to <i>standby mode</i> after a configurable time.
	11	Standby mode	When the Luminoscope® enters the <i>standby mode</i> , the LCD screen turns dark instantaneously, but the unit is not switched off.
	12	<b>Power</b> button on the <i>Optical block</i>	Wake the Luminoscope® up by pushing the <b>Power</b> button on the <i>Optical block</i> for 1 second. The <b>Program selection</b> screen 3 pops up immediately.
	13	Touch the screen	Wake the Luminoscope® up by pushing a random place on the LCD screen. The <b>Program selection</b> screen 3 pops up immediately.


## 6.3 Inactivity timer

In addition to the *standby mode* discussed in previous chapter, there is also an integrated timer feature that fully turns the unit off after a configurable longer inactivity period (*auto switch off* function).

<p>Figure 41: Automatically switching the Luminoscope® OFF</p>	14	Inactivity timer	<p>If the Luminoscope® is turned on but not used for a while (no button pressed, no lamp measured, etc.), it automatically switches to <i>standby mode</i>, darkening the LCD screen.</p> <p>If the inactivity period extends for a longer time, the Luminoscope® will be switched off completely. The Luminoscope® can be switched on again by pushing the <b>Power</b> button on the <i>Optical block</i> 1 on the connector panel of the optical block.</p>
--	----	------------------	--

## 6.4 Forced shut down of the Luminoscope®

This function provides a hardware power-off to be used only in cases of an unexpected operation.

	15	Forced shutdown	<p>Pressing the <b>Power</b> button on the <i>Optical block</i> for a time longer than 4 seconds will switch off the system immediately. This should only be used in case the system is blocked as a result of an unexpected operation.</p>
---	----	-----------------	---



---

# 7 Operation

---

The main purpose of the Luminoscope® is to measure specific headlamp beam characteristics such as horizontal beam position, vertical beam position, beam intensity, etc. There are different headlamp algorithms available for measuring the headlamp characteristics of different headlamp types. Based on the chosen algorithm, a number of the headlamp beam characteristics will be measured.

Most of the headlamp algorithms can be used either for adjusting the headlamp beam position or for checking the headlamp beam position. This means there are two different approaches for a test cycle:

- Headlamp aiming cycle: The position of the headlamp beam should be aimed (adjusted) to a pre-defined target position. An *aiming tolerance zone* around the target position allows the operator to adjust the headlamp correctly,
- Headlamp audit cycle: The position of the headlamp beam should be evaluated to check whether it is within the pre-defined *audit tolerance zone*.

The audit tolerance zone is in most cases determined by the government regulations. The *aiming tolerance zone* should always be smaller than the *audit tolerance zone*. This to ensure that a correctly aimed headlamp in a workshop (using the smaller *aiming tolerance zone*) will pass the test in a government inspection station (using the larger *audit tolerance zone*).

## 7.1 Test cycle references










There is a number of topics related with the test sequence which apply to many of its steps. They are collected below and will be used as a reference along the explanation of the test cycle.

### 7.1.1 Beam icons



Each low beam, high beam and fog beam has its specific beam icon on the cycle screens. Next table explains the meaning of the icons and the different statuses.

Icon	Beam	Status description
	Low beam	Headlamp under test (test not yet started).
	High beam	
	Fog beam	
	Low beam	Headlamp position inside tolerance. The tolerance overlay on the headlamp image is green-colored.
	High beam	
	Fog beam	
	Low beam	Headlamp position outside tolerance. The tolerance overlay on the headlamp image is red-colored.
	High beam	
	Fog beam	

Similarly, each low beam, high beam and fog beam has its specific beam icon on the **Beam selection** screen. Next table explains the meaning of the icons and the different statuses.

Icon	Beam	Status description
	Low beam	Headlamp not yet tested.
	High beam	
	Fog beam	
	Low beam	Headlamp position inside tolerance.
	High beam	
	Fog beam	
	Low beam	Headlamp position outside tolerance.
	High beam	
	Fog beam	

After the test, the system displays a datablock including the test results next to the corresponding beam icon on the **Beam selection** screen, regardless of the positive or negative test results.

Icon	Status description
	Approved headlamp with measurement results
	Rejected headlamp with measurement results

The datablocks for the results of each tested beam include the following information:

Value	Description
X	Horizontal beam measurement position (Left/Right)
Y	Vertical beam measurement position (Up/Down)
I	Intensity
H	Mounting height of the headlamp

Depending on the chosen algorithm and configuration of the system, the number of results so as the units may vary.

### 7.1.2 Left / right vehicle side definition

The left and right sides of the vehicle are always defined from the driver's point of view.

Headlamps which are located at the left side (as seen from the driver's point of view) are called the *left headlamps*, and those at the right side are called the *right headlamps*.

The touch screen of the Luminoscope® PLA 35 can be rotated 180° by pressing the **Rotate screen** button.

Consequently there are two possible screen orientations. One is better suited for checking headlamps and the other is preferred for adjusting headlamps.

Screen orientation mode	Description
Checking headlamps	The operator is standing behind the Luminoscope® system, looking towards the front of the vehicle and the touch screen.
Adjusting headlamps	The operator is standing nearby the zone between the Luminoscope® system and the front of the vehicle and is looking towards the lens of the Luminoscope® and the touch screen.

Rotating the screen position affects to the position of the beam icons and the beam selection buttons on the screen. The intelligence of the Luminoscope® automatically places the beam icons and beam selection buttons at the correct side of the vehicle. For both screen orientation modes, the beam icons and beam selection buttons which are closer to the left side of the vehicle are applicable for the headlamps at the left side. Those closer to the right side of the vehicle are applicable for the headlamps at the right side.




Figure 42: Left / right vehicle side definition

1	Left side of the vehicle	2	Right side of the vehicle
---	--------------------------	---	---------------------------

7.1.3 Alignment with the vehicle

Before each test cycle starts, it is necessary to align the optical axis of the headlamp tester with the longitudinal axis or driving direction of the vehicle, in order to minimize the measurement result error in the horizontal direction.

7.1.3.1 Alignment mirror

Use the alignment mirror on top of the stand to align the Luminoscope® with the longitudinal axis of the vehicle.




Figure 43: Use of alignment mirror to align the Luminoscope® with vehicle longitudinal axis

1. Move the Luminoscope® to the middle of the vehicle. Skip this step for the PLA 35 NR model.



**Remember:** In case of the PLA 35 NR model, the alignment should be performed for each vehicle side separately, i.e. once for the left headlamps and once for the right headlamps.

2. Rotate the mirror handle 3 until the lines 1 of the alignment mirror are visible at the front of the vehicle.
3. Rotate the stand slowly until one of the mirror lines 1 intersects two symmetrical points 2 of the vehicle.

The two symmetrical points should be as far apart as possible, close to the vehicle sides, in order to maximize the precision of the alignment.

### 7.1.3.2 Alignment laser

Use the optional green alignment laser on top of the stand to align the Luminoscope® with the longitudinal axis of the vehicle.




Figure 44: Use of alignment laser to align the Luminoscope® with vehicle longitudinal axis

1. Move the Luminoscope® to the middle of the vehicle. Skip this step for the PLA 35 NR model.



**Remember:** In case of the PLA 35 NR model, the alignment should be performed for each vehicle side separately, i.e. once for the left headlamps and once for the right headlamps.

2. Turn on the laser by pushing the **ON** button. The laser remains powered on for a preset timespan.
3. Rotate the laser handle 3 until the laser beam 1 is projected at the front of the vehicle.
4. Rotate the stand until the laser beam 1 intersects two symmetrical points 2 of the vehicle.  
The two symmetrical points should be as far apart as possible, close to the vehicle sides, in order to maximize the precision of the alignment.

Some bodywork colours may cause too much color absorption. In this case, either use the alignment mirror or open the front hood and project the laser beam on two symmetrical points at the inside.

### 7.1.4 Positioning in front of the headlamp

It is of great importance that the lens of the Luminoscope® is correctly positioned in front of the headlamp to ensure that as many light rays as possible enter the lens.

This guarantees that the beam image is displayed realistically on the white projection screen inside the Luminoscope® to be able to perform a correct headlamp measurement.

With this purpose, the Luminoscope® system is provided with the electronic *Position Check* system that uses twelve photocells around the lens 1.




Figure 45: Position Check cells around the lens

The electronic *Position Check* system guides the operator to the optimal position for measuring the headlamp beam by means of four *Position Check* arrows 2. Once the optimal position is reached, all *Position Check* arrows 2 disappear and the headlamp measurement starts automatically.




Figure 46: Position Check Arrows on control panel screen

In some situations, it is not possible to reach an optimal position in front of the headlamp using the *Position Check*. This could be caused, for example, because of a very wide headlamp beam. In such a case, the alignment operation can be done manually.

The operator positions the Luminoscope® in front of the headlamp by moving the optical block vertically and horizontally (without rotating the stand) and by simultaneously looking at the beam projection on the white projection screen inside the optical block. When the beam projection looks as expected, tap on the **Skip Position Check** button 3 to start the headlamp measurement.

### 7.1.5 Mounted height of the headlamp

The vertical target values and the vertical aiming and audit tolerances for European LHD and RHD low beams depend on the mounted height of the low beam. The targets and tolerances are defined in the *ECE R48* standard (part of *ECE 324* standard).

The *ECE R48* standard doesn't provide any information about the horizontal aiming or audit tolerances.



**Remember:** Target and tolerances are defined by local regulations and may vary from those explained below.

The standard defines four height ranges or zones for low beams:

Zone	Height range	Application
0,8 m > height	Lower than 0,8 m	These zones are typically used for workshop and inspection station equipment.
1,0 m ≥ height ≥ 0,8 m	Between 0,8 m and 1,0 m	
1,2 m ≥ height > 1,0 m	Higher than 1,0 m and not over 1,2 m	
Height > 1,2 m	Higher than 1,2 m	Reserved for some special vehicles such as off-road or military vehicles.

The specific vertical audit tolerance values for the different height zones are explained in the diagram below. The colored hatched areas are the initial vertical aiming tolerances as defined by the *ECE R48* regulation.




Figure 47: Vertical audit and aiming tolerance window depending on the mounting height of the low beam

1	Horizontal axis. Vertical inclination value for an European LHD or RHD low beam in cm/10m.
2	Vertical axis. Mounted height of the low beam in meter.
3	Low beam mounting height of 0,8 m.
4	Low beam mounting height between 0,8 m and 1,0 m.
5	Low beam mounting height of 1,0 m.
6	RHD low beam cut-off line simulation.
7	Audit tolerance window.
8	Measurement reference of the low beam cut-off line (V-point).
9	LHD low beam cut-off line simulation.
10	Vertical tolerance window for initial low beam aiming.

The higher the mounted height of the low beam, the lower the low beam inclination should be.

The next table shows an overview of the four *height zones* with the corresponding vertical aiming and audit tolerance window:

Low beam mounting height	Vertical audit tolerance window for low beam	Vertical aiming tolerance window for low beam
< 0,8 m	-5 cm/10m till -25 cm/10m	-10 cm/10m till -15 cm/10m
0,8 - 1,0 m	-5 cm/10m till -30 cm/10m	-10 cm/10m till -20 cm/10m
> 1,0 - ≤1.2 m	-10 cm/10m till -30 cm/10m	-15 cm/10m till -20 cm/10m
> 1,2 m	-15 cm/10m till -35 cm/10m	-20 cm/10m till -25 cm/10m

At the start of each headlamp measurement, it is necessary to determine the mounting height of the headlamp in order to select the corresponding vertical tolerance zone. For this purpose, the optical block has to be properly aligned in front of the headlamp, with the assistance of the *Position Check* system.

The cursor upper side 2 of the height indicator 1 on the sliding table, shows the exact mounting height of the headlamp, according with the reading on the sticker 3 on the PLA stand.




Figure 48: Height selection

After correctly positioning the Luminoscope® in front of the headlamp by using the *Position Check* system, the *Position Check Arrows* 4 should all disappear as on the image underneath.

At this point, one of the three height area buttons 5 should be tapped and the correct aiming or audit tolerance window will be automatically applied.




Figure 49: Lamp height area selection

**Note:** The height selection step should only be done before the first low beam measurement in the cycle. The second low beam in the cycle automatically uses the same defined height zone. This principle is also valid for the high and fog beams.

#### Related information

[Mounted height of the headlamp](#) (pg. 66)

### 7.1.6 ESL - Electronic Spirit Level module

The Luminoscope® may be provided with an optional on-board electronic level or *ESL* (Electronic Spirit Level).

Luminoscope® systems with a trolley base not running on adjustable guiding rails are equipped with the *ESL*. The *ESL* is mounted underneath the mechanical spirit level of the optical block.

It's unavoidable that the pitch angle and roll angle of the optical block of systems with non-adjustable rails or without any rails will vary while displacing the system. This has a direct consequence on the headlamp measurement results. As a solution, the Luminoscope® PLA 35 is equipped with an *ESL*.

The purpose of the *ESL* is to automatically take into account the pitch and roll angle of the optical block to ensure an accurate headlamp measurement. The headlamp measurement result is automatically compensated with the real time angular measurement of the *ESL*.

Before each headlamp measurement starts, the pitch (inclination) and roll angle of the optical block is measured by the *ESL*. As the Luminoscope® PLA 35 was moved, the *ESL* needs a short period to stabilize its angular measurement. The image underneath is shown as long as the *ESL* is stabilising. The icon of the *ESL* shows some "shivering" by means of two lines above and below the icon 1. At the same time the measured pitch and roll angle of the *ESL* are displayed 2.




Figure 50: ESL: data not stable

As soon as the *ESL* is stabilised, the screen disappears and the actual headlamp measurement starts automatically. The angular measurement values of the *ESL* are taken automatically into account. In case the Luminoscope® is (slightly) moved or shaken during the headlamp measurement, the *ESL* performs a new angular measurement and the above screen is displayed again. As soon as the *ESL* has been stabilised, the headlamp measurement resumes.

If however the pitch or roll angle exceed  $\pm 2,00\%$ , a warning message appears indicating that the spirit level is out of range. In this case the headlamp measurement cannot start.




Figure 51: ESL: data out of range

## 7.2 Test cycle sequence

This chapter explains the different steps that should be followed in a test cycle. Based on the Luminoscope® configuration or the selected program, a test cycle could be a headlamp aiming cycle or a headlamp audit cycle.

















**Remember:** The test cycle could look slightly different depending on the Luminoscope® configuration or selected program which could be based on different regulations.

Step number	Step description	Comments
1	Switching on the Luminoscope®	The Luminoscope® should be properly charged and switched on.
2	Alignment with the vehicle	The Luminoscope® should be properly aligned with the longitudinal axis (driving direction) of the vehicle.
3	Program selection	The <b>Program selection</b> screen displays different selectable test modes, which allow the operator to select among a number of pre-configured test cycles.
4	Line selection	The optional <b>Line selection</b> screen displays up to nine test lines from which the operator can choose. Each test line has a preset name and slope of the vehicle standing area.
5	Beam selection	The <b>Beam selection</b> screen provides buttons for the selection of the required beam and vehicle side.
6	Selection of mounted headlamp height	The <b>Height selection</b> screen shows the different headlamp mounting height zones for each beam type (low, high and fog beam) separately. At the start of each headlamp measurement, it is necessary to determine the mounting height of the headlamp in order to select the corresponding vertical tolerance zone.
7	Positioning in front of the headlamp	Before the headlamp measurement can start, it is required to position the Luminoscope® correctly in front of the headlamp by means of the electronic <i>Position Check</i> system.
8	ESL (Electronic Spirit Level) module compensation	The <i>ESL</i> (Electronic Spirit Level) module automatically takes into account the pitch and roll angles of the optical block to ensure an accurate headlamp measurement.
9	Beam measurement	The digital camera inside the Luminoscope® captures, processes and analyzes the headlamp beam projection.
10	Overview beam measurement results	When all tests have been finished, the <b>Beam selection</b> screen shows all beam measurement results.
11	Test cycle reports and data transmission	Depending on the configuration of the Luminoscope®, the measurement results can be stored on the system ( <i>PDF</i> format), printed on a paper ticket or transmitted to an external device using one of the communication protocols.

### 7.2.1 Switching on the Luminoscope®

The Luminoscope® should be properly charged and switched on.

1. Switch on the Luminoscope®.
2. Make sure the Luminoscope® is properly charged.  
Look at the battery status icon at the top right corner of the screen.

Charger		Battery status description
Connected	Disconnected	
		Fully charged.
		Charge level between 100% and 75%.
		Charge level between 75% and 50%.
		Charge level between 50% and 25%.
		Charge level below 25%.
		Very low charge level.
		Battery disconnected.
		Charge too low for operation.



**CAUTION:** Do not connect the charger in case the rechargeable battery is not connected or broken.

#### Related tasks

[System restarting and power-off](#) (pg. 134)

### 7.2.2 Alignment with the vehicle

The Luminoscope® should be properly aligned with the longitudinal axis (driving direction) of the vehicle.

1. Use the alignment mirror on top of the stand to align the Luminoscope® with the longitudinal axis of the vehicle, or
2. Use the optional green alignment laser on top of the stand to align the Luminoscope® with the longitudinal axis of the vehicle.



#### Remember:

- In case the Luminoscope® is used on a rail guiding system (e.g. PLA 35 SR – Single Rail or PLA 35 DR – Double Rail), the stand should not be rotated during the cycle, particularly when moving the Luminoscope® from one side of the vehicle to the other side.

- In case the Luminoscope® is NOT used on a rail guiding system (e.g. PLA 35 NR – No rail), the alignment procedure should be performed separately for each headlamp at the left and right sides of the vehicle.

#### Related information

[Alignment with the vehicle](#) (pg. 62)

### 7.2.3 Program selection

The **Program selection** screen displays different selectable test modes, which allow the operator to select among a number of pre-configured test cycles.



**Remember:** The screen may have a different appearance depending on the customer's specific implementation.




Figure 52: **Program selection** screen

#	Button	Description
1	<b>Aiming</b> button	The <b>Screwdriver</b> button refers to a headlamp aiming cycle. In a headlamp aiming cycle, the position of the headlamp beam should be aimed (adjusted) to a pre-defined target position. An aiming tolerance zone around the target position allows the operator to adjust the headlamp correctly.

#	Button	Description
2	<b>Audit</b> button	The <b>Eye</b> button refers to a headlamp audit cycle. In a headlamp audit cycle, the position of the headlamp beam should be evaluated to check whether it is within the pre-defined audit tolerance zone. The audit tolerance zone is determined by the government regulations. The aiming tolerance zone should always be smaller than the audit tolerance zone. This to ensure that a correctly aimed headlamp in a workshop (using the smaller aiming tolerance zone) will pass the test in a government inspection station (using the larger audit tolerance zone).
3	<b>OEM</b> button	The <b>OEM</b> button refers to special Original Equipment Manufacturer sequences for various beam types.

Tap on one of the buttons for accessing the desired functionality:

- Tap on the **Aiming** button 1 to start a test in aiming mode.
- Tap on the **Audit** button 2 to start a test in audit mode.
- Tap on the **OEM** button 3 to enter the **OEM program selection** screen.

#### Related tasks

[OEM test cycle sequences](#) (pg. 99)

### 7.2.4 Line selection

The optional **Line selection** screen displays up to nine test lines from which the operator can choose. Each test line has a preset name and slope of the vehicle standing area.

The slope of a vehicle standing area can be positive (the front axle of the vehicle is positioned higher than the rear axle), negative (the front axle of the vehicle is positioned lower than the rear axle) or zero (both front and rear axle of the vehicle are positioned at the same height).



**Attention:** In case the device is only used at one location (only one test line), the **Line selection** screen is not displayed. However, the preset slope of the vehicle standing area of the first test line will be applied automatically to the beam measurement.



**Remember:** The screen may have a different appearance depending on the customer's specific implementation.




Figure 53: **Line selection** screen

#	Button	Description
1	Line selection	Select the test line. Each <b>Line selection</b> button shows the preset name and slope of the vehicle standing area.
2	Abort	Abort the test cycle and return to the <b>Program selection</b> screen.

Select the requested test line by tapping on the corresponding **Line selection** button.

The preset slope of the vehicle standing area will be applied automatically to the beam measurement.


### 7.2.5 Beam selection

The **Beam selection** screen provides buttons for the selection of the required beam and vehicle side.

Select the desired beam by tapping on the corresponding button and vehicle side.



**Remember:** The screen may have a different appearance depending on the customer's specific implementation.

Figure 54: **Beam selection** screen

#	Button	Description
1	First low beam	Enable the test of the first low beam.
2	First high beam	Enable the test of the first high beam.
3	First fog beam	Enable the test of the first fog beam.
4	Second low beam	Enable the test of the second low beam.
5	Second high beam	Enable the test of the second high beam.
6	Second fog beam	Enable the test of the second fog beam.
7	Screen rotation	Change the screen orientation.
8	Abort	Abort the test cycle and return to the <b>Program selection</b> screen.
9	Send results	Store the measurement results of the test cycle. Depending on the configuration of the Luminoscope®, the measurement results can be stored on the system (PDF format), printed on a paper ticket or transmitted to an external device using one of the communication protocols.



**Remember:** Rotating the screen position affects to the position of the beam icons and beam selection buttons on the screen. The intelligence of the Luminoscope® automatically places the beam icons and beam selection buttons at the correct side of the vehicle. For both screen orientation modes, the beam icons and beam selection buttons which are closer to the left side of the vehicle are applicable for the headlamps on the left side. Those closer to the right side of the vehicle are applicable for the headlamps on the right side.

#### Related information

[Left / right vehicle side definition](#) (pg. 60)

## 7.2.6 Selection of mounted headlamp height

The **Height selection** screen shows the different headlamp mounting height zones for each beam type (low, high and fog beam) separately. At the start of each headlamp measurement, it is necessary to determine the mounting height of the headlamp in order to select the corresponding vertical tolerance zone.



**Remember:** The screen may have a different appearance, depending on the customer's specific implementation and on the local specific height zones regulations.




Figure 55: **Height selection** screen

1. Position the Luminoscope® in front of the headlamp by means of the electronic *Position Check* system 1. Once the optimal position is reached, all *Position Check Arrows* disappear (as shown on the image above).
2. Read the exact mounting height of the headlamp on the height sticker on the PLA stand by using the height indicator on the sliding table of the *Optical block*.
3. Tap on the corresponding **Height zone** buttons 2.

### Related tasks

[Positioning in front of the headlamp](#) (pg. 77)

### Related information

[Mounted height of the headlamp](#) (pg. 66)

## 7.2.7 Positioning in front of the headlamp

Before the headlamp measurement can start, it is required to position the Luminoscope® correctly in front of the headlamp by means of the electronic *Position Check* system.



**CAUTION:** A correct positioning of the Luminoscope® in front of the headlamp is necessary for an accurate headlamp measurement.



**Remember:** As a result of the previous *Selection of mounted headlamp height* step, the optical block should already be correctly positioned in front of the headlamp.




Figure 56: **Position Check** screen

1. Position the Luminoscope® in front of the headlamp under test 2 (the beam icon is displayed in yellow) by means of the black *Position Check Arrows* 1.
2. Move the optical block vertically and / or horizontally (without rotating the stand) towards the direction of the arrows.

If the optimal position in front of the headlamp is achieved, the Luminoscope® automatically proceeds to the next phase in the test cycle.



**Remember:** In some situations it is not possible to reach an optimal position in front of the headlamp using the *Position Check*. This could be caused, for example, because of a very wide headlamp beam. In such a case, the alignment operation can be done manually.

3. Only in case of manual alignment operation: the operator positions the Luminoscope® in front of the headlamp by moving the optical block vertically and horizontally (without rotating the stand) and by simultaneously looking at the beam projection on the white projection screen inside the optical block.
4. Once the beam projection looks as expected, tap on the **Skip Position Check** button 3.

## Related tasks

[Positioning in front of the headlamp](#) (pg. 77)

### 7.2.8 ESL (Electronic Spirit Level) module compensation

The *ESL* (Electronic Spirit Level) module automatically takes into account the pitch and roll angles of the optical block to ensure an accurate headlamp measurement.



**Remember:** Depending on the Luminoscope® configuration, it may be provided with an on-board *ESL*. Consequently, the screen underneath will not appear on the Luminoscope® screen if there is no *ESL*.

When not stable conditions are detected, the following screen is displayed.




Figure 57: *ESL* (Electronic Spirit Level) module screen

Wait until the *ESL* stabilizes.

As soon as the *ESL* is stabilised, the screen disappears and the actual headlamp measurement starts automatically. The angular measurement values of the *ESL* are taken automatically into account for the headlamp measurement.



**Remember:** In case the Luminoscope® is (slightly) moved or shaken during the headlamp measurement, the *ESL* performs a new angular measurement and the above screen is displayed again. As soon as the *ESL* has been stabilized, the headlamp measurement resumes.

## Related information

[ESL \(Electronic Spirit Level\) module](#) (pg. 69)

## 7.2.9 Beam measurement

The digital camera inside the Luminoscope® captures, processes and analyzes the headlamp beam projection.

The following sections explain the headlamp test procedure for a common and complete set of headlamps including:

- two ECE low beams,
- two high beams and
- two fog beams.



**Remember:** The test sequence could look slightly different depending on the Luminoscope® configuration or selected program, which could be based on different regulations.

### Related information

[Headlamps](#) (pg. 19)

[Headlamp icons](#) (pg. 59)

### 7.2.9.1 Low beam test

#### 7.2.9.1.1 Aiming mode

This chapter explains the low beam test in case the **Aiming** button (screwdriver button) has been tapped in the **Program selection** screen.

The next screen is displayed as soon as the first ECE low beam test starts.



**Remember:** The screen is identical for the second low beam (with the exception of the indication of the beam icons on top of the screen).

In case of an ECE LHD (Left Hand Drive) low beam:




Figure 58: Example of an LHD low beam

1	<b>Position Check Arrows</b>	Indicates the direction(s) on which the optical block should be moved to achieve the optimal position in front of the headlamp. This position can change when adjusting the headlamp.
2	<b>Information field</b>	Depending on the Luminoscope® configuration, some related information such as the name of the selected program (Vehicle), the name of the test (Beam), license plate, etc. will be displayed.
3	<b>Live headlamp beam image</b>	Real time image of the headlamp beam including overlays for tolerance zone(s), algorithm measurement position, etc.
4	<b>First low beam icon</b>	First low beam icon indicating the status of the beam. The meaning of the icon depends on its shape and color: <ul style="list-style-type: none"> <li>• <b>Yellow</b> mark means <i>Test in progress</i>.</li> <li>• <b>Green</b> V-sign means <i>Within tolerance</i>.</li> <li>• <b>Red</b> cross means <i>Out of tolerance</i>.</li> </ul>
5	<b>Information banner</b>	The information banner shows different status messages such as: <b>Test in progress</b> , <b>Within tolerance</b> , <b>Out of tolerance</b> , etc. Status, error or warning messages can also be displayed over there.
6	<b>Rotate screen button</b>	Rotate the screen position.
7	<b>Validation button</b>	If the <i>live validation</i> function is activated, tapping on this button will store the beam measurement result. The result is unconditionally stored whether the algorithm measurement position is <i>Within tolerance</i> or <i>Out of tolerance</i> .
8	<b>Audit tolerance zone</b>	The <i>audit tolerance zone</i> allows the operator to check if the headlamp is within the audit tolerances that are applicable in a government inspection station.
9	<b>Aiming tolerance zone</b>	The <i>aiming tolerance zone</i> allows the operator to adjust the headlamp correctly. Note that the aiming tolerance zone should always be smaller than the audit tolerance zone. This is to ensure that a correctly aimed headlamp at a workshop ( <i>using the smaller aiming tolerance zone</i> ) will pass the test in a government inspection station ( <i>using the larger audit tolerance zone</i> ).

10	Algorithm measurement position	The algorithm overlay (red cross) represents the algorithm measurement position on the headlamp beam image. In case of an aiming cycle, the red cross position should be aimed towards the center of the aiming tolerance zone. In case of an audit cycle, the red cross position is evaluated. The actual position is displayed at the headlamp measurement result field.
11	Beam direction arrows	<p>The beam direction arrows indicate the direction(s) in which the headlamp should be moved to reach the target position inside the tolerance zone.</p> <p>The color of the arrows indicates the live status of the aiming:</p> <ul style="list-style-type: none"> <li>• <b>Green</b> means the result is <i>inside</i> the tolerance zone.</li> <li>• <b>Yellow</b> means the result is <i>close</i> to the tolerance zone.</li> <li>• <b>Red</b> means the result is <i>far away</i> from the tolerance zone.</li> </ul>
12	Headlamp measurement results field	Depending on the chosen algorithm and Luminoscope® configuration, headlamp measurement results such as horizontal beam position (X), vertical beam position (Y), headlamp mounting height (H), etc are displayed here.
13	ESL (Electronic Spirit Level) module angles	Measured Pitch and Roll angle of the ESL (Electronic Spirit Level) module, if applicable.
14	<b>Cut-off angle</b> button	Each time the <b>Cut-off angle</b> button is tapped, the selected angle of the low beam tolerance overlay changes between 15° and 45°. In most common cases the default selection of 15° can be used. Use the 45° selection only for <i>ECE</i> low beam <i>cut-off</i> lines with a 45° step. It is important to correctly set the angle because it has a direct consequence on the horizontal algorithm measurement position (determination of the <i>V-point</i> ) of the <i>cut-off</i> line.

### Cycle description

1. Adjust the beam position until the algorithm measurement position (red cross) is inside the aiming tolerance zone.
2. Tap on the **Validation** button 1 to store the beam measurement result.  
The result is unconditionally stored whether the algorithm measurement position is *Within tolerance* or *Out of tolerance*.




Figure 59: LHD low beam test screen

The **Beam selection** screen appears and the headlamp measurement results are displayed next to the corresponding beam selection button 2.

**Note:** Depending on some Luminoscope® configuration parameters, the *headlamp intensity* may be automatically measured after tapping on the **Validation** button 1.




Figure 60: Low beam test results on **Beam selection** screen

## Test Repetition

If required, repeat the test. Proceed as follows.

Tap again on the corresponding beam selection button.

## Testing the second low beam

Once the first low beam test is completed, it is usually required to test the second low beam.

1. Move the Luminoscope® in front of the second low beam.
2. Tap on the **Second low beam** button on the **Beam selection** screen 3.



**Remember:** The height selection should only be done before the first low beam measurement in the cycle. The selected height zone is copied automatically for the second low beam.

3. Repeat the step *Positioning in front of the headlamp*.  
Make sure the optical block is correctly positioned in front of the second low beam.

### Related tasks

[Positioning in front of the headlamp](#) (pg. 77)

#### 7.2.9.1.2 Audit mode

This chapter explains the low beam test in case the **Audit** button (eye button) has been tapped in the **Program selection** screen.

When tapping the **Audit** button (eye button), the same low beam audit tolerances that are of application in the official Belgian *GOCA (Groupement des entreprises agréées de contrôle automobile et du permis de conduire)* inspection stations are used. The low beam audit tolerances meet the specification sheet of GOCA of 2016. Note that only the vertical position of the low beams is measured and this on the horizontal part of the low beam cut-off line (between -3,5% and -5,5% on the horizontal axis). The aiming tolerance zone is not shown.

The next screen is displayed as soon as the first ECE low beam test starts.



**Remember:** The screen is identical for the second low beam (with the exception of the indication of the beam icons on top of the screen).

In case of an ECE LHD (Left Hand Drive) low beam:




Figure 61: Example of an LHD low beam

1	<b>Position Check Arrows</b>	Indicates the direction(s) on which the optical block should be moved to achieve the optimal position in front of the headlamp. This position can change when adjusting the headlamp.
2	<b>Information field</b>	Depending on the Luminoscope® configuration, some related information such as the name of the selected program (Vehicle), the name of the test (Beam), license plate, etc. will be displayed.
3	<b>Live headlamp beam image</b>	Real time image of the headlamp beam including overlays for tolerance zone(s), algorithm measurement position, etc.
4	<b>First low beam icon</b>	First low beam icon indicating the status of the beam. The meaning of the icon depends on its shape and color: <ul style="list-style-type: none"> <li>• <b>Yellow</b> mark means <i>Test in progress</i>.</li> <li>• <b>Green</b> V-sign means <i>Within tolerance</i>.</li> <li>• <b>Red</b> cross means <i>Out of tolerance</i>.</li> </ul>
5	<b>Information banner</b>	The information banner shows different status messages such as: <b>Test in progress</b> , <b>Within tolerance</b> , <b>Out of tolerance</b> , etc. Status, error or warning messages can also be displayed over there.
6	<b>Rotate screen button</b>	Rotate the screen position.
7	<b>Validation button</b>	If the <i>live validation</i> function is activated, tapping on this button will store the beam measurement result. The result is unconditionally stored whether the algorithm measurement position is <i>Within tolerance</i> or <i>Out of tolerance</i> .
8	<b>Audit tolerance zone</b>	The <i>audit tolerance zone</i> allows the operator to check if the headlamp is within the audit tolerances that are applicable in a government inspection station.
9	<b>Algorithm measurement position</b>	The algorithm overlay (red cross) represents the algorithm measurement position on the headlamp beam image. In case of an aiming cycle, the red cross position should be aimed towards the center of the aiming tolerance zone. In case of an audit cycle, the red cross position is evaluated. The actual position is displayed at the headlamp measurement result field.

10	Beam direction arrows	<p>The beam direction arrows indicate the direction(s) in which the headlamp should be moved to reach the target position inside the tolerance zone.</p> <p>The color of the arrows indicates the live status of the aiming:</p> <ul style="list-style-type: none"> <li>• <b>Green</b> means the result is <i>inside</i> the tolerance zone.</li> <li>• <b>Yellow</b> means the result is <i>close</i> to the tolerance zone.</li> <li>• <b>Red</b> means the result is <i>far away</i> from the tolerance zone.</li> </ul>
11	Headlamp measurement results field	Depending on the chosen algorithm and Luminoscope® configuration, headlamp measurement results such as horizontal beam position (X), vertical beam position (Y), headlamp mounting height (H), etc are displayed here.
12	ESL (Electronic Spirit Level) module angles	Measured Pitch and Roll angle of the ESL (Electronic Spirit Level) module, if applicable.

### Cycle description

1. Check if the beam position is inside the *audit tolerance zone*.
2. If not, and if it is allowed to aim the headlamp on the spot, adjust the beam position towards applicable vertical target value.
3. Tap on the **Validation** button 1 to store the beam measurement result.  
The result is unconditionally stored whether the algorithm measurement position is *Within tolerance* or *Out of tolerance*.




Figure 62: LHD low beam test screen

The **Beam selection** screen appears and the headlamp measurement results are displayed next to the corresponding beam selection button 2.

**Note:** Depending on some Luminoscope® configuration parameters, the *headlamp intensity* may be automatically measured after tapping on the **Validation** button 1.




Figure 63: Low beam test results on **Beam selection** screen

### Test Repetition

If required, repeat the test. Proceed as follows.

Tap again on the corresponding beam selection button.

### Testing the second low beam

Once the first low beam test is completed, it is usually required to test the second low beam.

1. Move the Luminoscope® in front of the second low beam.
2. Tap on the **Second low beam** button on the **Beam selection** screen 3.



**Remember:** The height selection should only be done before the first low beam measurement in the cycle. The selected height zone is copied automatically for the second low beam.

3. Repeat the step *Positioning in front of the headlamp*.  
Make sure the optical block is correctly positioned in front of the second low beam.

### Related tasks

[Positioning in front of the headlamp](#) (pg. 77)

### 7.2.9.2 High beam test

The next screen is displayed as soon as the first high beam test starts.



**Remember:** The screen is identical for the second high beam (with the exception of the indication of the beam icons on top of the screen).




Figure 64: Example of a high beam

1	Position Check Arrows	Indicates the direction(s) on which the optical block should be moved to achieve the optimal position in front of the headlamp. This position can change when adjusting the headlamp.
2	Information field	Depending on the Luminoscope® configuration, some related information such as the name of the selected program (Vehicle), the name of the test (Beam), license plate, etc. will be displayed.
3	Live headlamp beam image	Real time image of the headlamp beam including overlays for tolerance zone(s), algorithm measurement position, etc.
4	First high beam icon	First high beam icon indicating the status of the beam. The meaning of the icon depends on its shape and color: <ul style="list-style-type: none"> <li>• <b>Yellow</b> mark means <i>Test in progress</i>.</li> <li>• <b>Green</b> V-sign means <i>Within tolerance</i>.</li> <li>• <b>Red</b> cross means <i>Out of tolerance</i>.</li> </ul>
5	Information banner	The information banner shows different status messages such as: <b>Test in progress</b> , <b>Within tolerance</b> , <b>Out of tolerance</b> , etc. Status, error or warning messages can also be displayed over there.
6	Rotate screen button	Rotate the screen position.
7	Validation button	If the <i>live validation</i> function is activated, tapping on this button will store the beam measurement result. The result is unconditionally stored whether the algorithm measurement position is <i>Within tolerance</i> or <i>Out of tolerance</i> .

8	Audit tolerance zone	The <i>audit tolerance zone</i> allows the operator to check if the headlamp is within the audit tolerances that are applicable in a government inspection station.
9	Aiming tolerance zone	The aiming tolerance zone allows the operator to adjust the headlamp correctly. Note that the aiming tolerance zone should always be smaller than the audit tolerance zone. This is to ensure that a correctly aimed headlamp at a workshop ( <i>using the smaller aiming tolerance zone</i> ) will pass the test in a government inspection station ( <i>using the larger audit tolerance zone</i> ).
10	Algorithm measurement position	The algorithm overlay (red cross) represents the algorithm measurement position on the headlamp beam image. In case of an aiming cycle, the red cross position should be aimed towards the center of the aiming tolerance zone. In case of an audit cycle, the red cross position is evaluated. The actual position is displayed at the headlamp measurement result field.
11	Beam direction arrows	<p>The beam direction arrows indicate the direction(s) in which the headlamp should be moved to reach the target position inside the tolerance zone.</p> <p>The color of the arrows indicates the live status of the aiming:</p> <ul style="list-style-type: none"> <li>• <b>Green</b> means the result is <i>inside</i> the tolerance zone.</li> <li>• <b>Yellow</b> means the result is <i>close</i> to the tolerance zone.</li> <li>• <b>Red</b> means the result is <i>far away</i> from the tolerance zone.</li> </ul>
12	Headlamp measurement results field	Depending on the chosen algorithm and Luminoscope® configuration, headlamp measurement results such as horizontal beam position (X), vertical beam position (Y), headlamp mounting height (H), etc are displayed here.
13	ESL (Electronic Spirit Level) module angles	Measured Pitch and Roll angle of the ESL (Electronic Spirit Level) module, if applicable.

**In case of an *aiming* cycle:**

1. Adjust the beam position until the algorithm measurement position (red cross) is inside the aiming tolerance zone.

**In case of an *audit* cycle:**

2. Check if the beam position is inside the *audit tolerance zone*.
3. If not, and if it is allowed to aim the headlamp on the spot, adjust the beam position inside the *aiming tolerance zone*.

**For both aiming and audit cycles:**

4. Tap on the **Validation** button 1 to store the beam measurement result.  
The result is unconditionally stored whether the algorithm measurement position is *Within tolerance* or *Out of tolerance*.




Figure 65: High beam test screen

The **Beam selection** screen appears and the headlamp measurement results are displayed next to the corresponding beam selection button 2.

**Note:** Depending on some Luminoscope® configuration parameters, the *headlamp intensity* may be automatically measured after tapping on the **Validation** button 1.




Figure 66: High beam test results on **Beam selection** screen

**Eventually repeating the test on the same high beam:**

5. If required, repeat the test by tapping again on the corresponding beam selection button.

**Testing the second high beam:**

6. Move the Luminoscope® in front of the second high beam.

7. Tap on the **Second high beam** button on the **Beam selection** screen 3.



**Remember:** The height selection should only be done before the first high beam measurement in the cycle. The selected height zone is copied automatically for the second high beam.

**8.** Repeat the step *Positioning in front of the headlamp*.

Make sure the optical block is correctly positioned in front of the second high beam.

### Related tasks

[Positioning in front of the headlamp](#) (pg. 77)

### 7.2.9.3 Fog beam test

The next screen is displayed as soon as the first fog beam test starts.



**Remember:** The screen is identical for the second fog beam (with the exception of the indication of the beam icons on top of the screen).




Figure 67: Example of a fog beam

1	<i>Position Check Arrows</i>	Indicates the direction(s) on which the optical block should be moved to achieve the optimal position in front of the headlamp. This position can change when adjusting the headlamp.
2	Information field	Depending on the Luminoscope® configuration, some related information such as the name of the selected program (Vehicle), the name of the test (Beam), license plate, etc. will be displayed.
3	Live headlamp beam image	Real time image of the headlamp beam including overlays for tolerance zone(s), algorithm measurement position, etc.

4	First fog beam icon	First fog beam icon indicating the status of the beam. The meaning of the icon depends on its shape and color: <ul style="list-style-type: none"> <li>• <b>Yellow</b> mark means <i>Test in progress</i>.</li> <li>• <b>Green</b> V-sign means <i>Within tolerance</i>.</li> <li>• <b>Red</b> cross means <i>Out of tolerance</i>.</li> </ul>
5	Information banner	The information banner shows different status messages such as: <b>Test in progress</b> , <b>Within tolerance</b> , <b>Out of tolerance</b> , etc. Status, error or warning messages can also be displayed over there.
6	<b>Rotate screen</b> button	Rotate the screen position.
7	<b>Validation</b> button	If the <i>live validation</i> function is activated, tapping on this button will store the beam measurement result. The result is unconditionally stored whether the algorithm measurement position is <i>Within tolerance</i> or <i>Out of tolerance</i> .
8	Audit tolerance zone	The <i>audit tolerance zone</i> allows the operator to check if the headlamp is within the audit tolerances that are applicable in a government inspection station.
9	Aiming tolerance zone	The aiming tolerance zone allows the operator to adjust the headlamp correctly. Note that the aiming tolerance zone should always be smaller than the audit tolerance zone. This is to ensure that a correctly aimed headlamp at a workshop ( <i>using the smaller aiming tolerance zone</i> ) will pass the test in a government inspection station ( <i>using the larger audit tolerance zone</i> ).
10	Algorithm measurement position	The algorithm overlay (red cross) represents the algorithm measurement position on the headlamp beam image. In case of an aiming cycle, the red cross position should be aimed towards the center of the aiming tolerance zone. In case of an audit cycle, the red cross position is evaluated. The actual position is displayed at the headlamp measurement result field.
11	Beam direction arrows	The beam direction arrows indicate the direction(s) in which the headlamp should be moved to reach the target position inside the tolerance zone.  The color of the arrows indicates the live status of the aiming: <ul style="list-style-type: none"> <li>• <b>Green</b> means the result is <i>inside</i> the tolerance zone.</li> <li>• <b>Yellow</b> means the result is <i>close</i> to the tolerance zone.</li> <li>• <b>Red</b> means the result is <i>far away</i> from the tolerance zone.</li> </ul>
12	Headlamp measurement results field	Depending on the chosen algorithm and Luminoscope® configuration, headlamp measurement results such as horizontal beam position (X), vertical beam position (Y), headlamp mounting height (H), etc are displayed here.
13	ESL (Electronic Spirit Level) module angles	Measured Pitch and Roll angle of the ESL (Electronic Spirit Level) module, if applicable.

**In case of an *aiming* cycle:**

1. Adjust the beam position until the algorithm measurement position (red cross) is inside the aiming tolerance zone.

**In case of an *audit* cycle:**

2. Check if the beam position is inside the *audit tolerance zone*.
3. If not, and if it is allowed to aim the headlamp on the spot, adjust the beam position inside the *aiming tolerance zone*.

**For both aiming and audit cycles:**

4. Tap on the **Validation** button 1 to store the beam measurement result.  
The result is unconditionally stored whether the algorithm measurement position is *Within tolerance* or *Out of tolerance*.




Figure 68: Fog beam test screen

The **Beam selection** screen appears and the headlamp measurement results are displayed next to the corresponding beam selection button 2.

**Note:** Depending on some Luminoscope® configuration parameters, the *headlamp intensity* may be automatically measured after tapping on the **Validation** button 1.




Figure 69: Fog beam test results on **Beam selection** screen

**Eventually repeating the test on the same fog beam:**

5. If required, repeat the test by tapping again on the corresponding beam selection button.

**Testing the second fog beam:**

6. Move the Luminoscope® in front of the second fog beam.
7. Tap on the **Second fog beam** button on the **Beam selection** screen 3.



**Remember:** The height selection should only be done before the first fog beam measurement in the cycle. The selected height zone is copied automatically for the second fog beam.

8. Repeat the step *Positioning in front of the headlamp*.  
Make sure the optical block is correctly positioned in front of the second fog beam.

**Related tasks**

[Positioning in front of the headlamp](#) (pg. 77)

**7.2.10 Beam measurement results**

When all tests are completed, the **Beam selection** screen displays all beam measurement results.




Figure 70: Overview of beam measurement results



**Remember:** If required, each test can be repeated by tapping on the corresponding beam selection button again.

### 7.2.11 Test cycle reports

Depending on the configuration of the Luminoscope®, the measurement results can be stored on the system (PDF format), printed on a paper ticket or transmitted to an external device using one of the communication protocols.

1. Tap on the **Send results** button 1.




Figure 71: **Send results** button on **Beam selection** screen

2. Enter the *license plate number* of the vehicle (or leave it empty if not required) and tap on the **Validation** button 2. The license plate entered becomes part of the file name of the produced file.

Alternatively, tap on the **Abort** button 3 to cancel the operation.




Figure 72: **License plate input** screen

In case the Luminoscope® is configured to store the results on the system (PDF format), the file is now created.

In case the Luminoscope® is configured to use a ticket printer, the ticket is now printed.

The **Program selection** screen will be displayed again. The Luminoscope® is ready to start a new test cycle.

### 7.2.11.1 Test report as a PDF file

In the case the Luminoscope® is configured to store the measurement results on the system (PDF format), the generated reports can be exported afterwards to a USB stick via the Export functionality.



**Remember:** The report layout depends on the Luminoscope® configuration and on the selected program, and consequently the format of the report below may differ.



	Vaartlaan 20 B-9800 Deinze Tel : +32 9 381 87 87 Website : www.let.be Email : info@let.be			
Garage: OK-cars Type / Marque: LUMINOSCOPE Model / Modèle: PLA35 Serienummer / N° série: EP200010.123 Softwareversie / Version Logiciel: xx.xx.xx LM35_XXXX				
Datum, tijd / Date, heure: 25/02/2020 10:09:23 Programma / Programme: LHD Nummerplaat / N° d'immatriculation: 1-LET-123				
Lamphoogte dimlichten / Hauteur feux de croisement: <0,8 m				
	LR / GD	ON / HB	STATUS / ETAT	I
Voor instelling / Avant réglage:				
DIM L / FCR G:	1,40 %	-0,42 %	-	-
DIM R / FCR D:	0,50 %	-1,09 %	-	-
Na instelling / Après réglage:				
DIM L / FCR G:	-0,49 %	-1,20 %	OK	31,7 kCd
DIM R / FCR D:	-0,01 %	-1,18 %	OK	30,5 kCd
Lamphoogte grootlichten / Hauteur feux de route: <0,8 m				
	LR / GD	ON / HB	STATUS / ETAT	I
Voor instelling / Avant réglage:				
GROOT L / FDR G:	0,59 %	1,02 %	-	-
GROOT R / FDR D:	-1,41 %	-0,51 %	-	-
Na instelling / Après réglage:				
GROOT L / FDR G:	0,58 %	-0,16 %	OK	42,0 kCd
GROOT R / FDR D:	-0,04 %	-0,19 %	OK	40,9 kCd
Lamphoogte mistlichten / Hauteur feux anti-brouillard: <0,8 m				
	LR / GD	ON / HB	STATUS / ETAT	I
Voor instelling / Avant réglage:				
MIST L / FAB G:	-	-5,05 %	-	-
MIST R / FAB D:	-	-1,02 %	-	-
Na instelling / Après réglage:				
MIST L / FAB G:	-	-5,06 %	NOK	10,3 kCd
MIST R / FAB D:	-	-2,27 %	OK	10,4 kCd
Voertuigstatus / Résultat du véhicule: OK				
1/1				

Figure 73: Example of a test report

Parameter	Description
Garage	Customer name.
Type	Luminoscope®.

Parameter	Description
Model / Modèle	Model of Luminoscope®.
Serienummer / N° série	Serial number of the Luminoscope® optical block.
Softwareversie / Version Logiciel	Software version of the Luminoscope®.
Datum, tijd / Date, heure	Date and time of the test.
Programma / Programme	Selected program.
Nummerplaat / N° de immatriculation	License plate number of the vehicle.
Lamphoogte dimlichten / Hauteur feux de croisement	Selected mounting height zone of the low beams.
Dim L / Fcr G	Measurement results of the left low beam in the specified units: Horizontal beam position (L/R), vertical beam position (U/D), Status (OK or NOK) and intensity (I).
Dim R / Fcr D	Measurement results of the right low beam in the specified units: Horizontal beam position (L/R), vertical beam position (U/D), Status (OK or NOK) and intensity (I).
Lamphoogte grootlichten / Hauteur feux de route	Selected mounting height zone of the high beams.
Groot L / Fdr G	Measurement results of the left high beam in the specified units: Horizontal beam position (L/R), vertical beam position (U/D), Status (OK or NOK) and intensity (I).
Groot R / Fdr D	Measurement results of the right high beam in the specified units: Horizontal beam position (L/R), vertical beam position (U/D), Status (OK or NOK) and intensity (I).
Lamphoogte mistlichten / Hauteur feux anti-brouillard	Selected mounting height zone of the fog beams.
Mist L / Fab G	Measurement results of the left fog beam in the specified units: Horizontal beam position (L/R), vertical beam position (U/D), Status (OK or NOK) and intensity (I).
Mist R / Fab D	Measurement results of the right fog beam in the specified units: Horizontal beam position (L/R), vertical beam position (U/D), Status (OK or NOK) and intensity (I).

### Related tasks

[Exporting test results to a USB stick](#) (pg. 143)

#### 7.2.11.2 Test report as printed ticket

Depending on the configuration of the Luminoscope®, the measurement results can be printed on a ticket printer.

This ticket printer may be connected to the Luminoscope® either via a serial line or over a *Bluetooth* link.



**Remember:** The ticket layout depends on the Luminoscope® configuration and on the selected program, and consequently the format of the ticket below may differ.

```

Garage: xxxxxxxx

Type: Luminoscope PLA 35

Serienummer: EP200010.123

Datum, tijd: 11/10/2020 08: 11: 37

Programma: LHD

Nummerplaat: 1-LET-123

-----
Resultaten: L/R(%); O/N(%); Status: I(kCd)

Dimlichthoogte: -800mm
DIM L: : -0,49; -1,20; P; 31,7
DIM R: : -0,01 -1,18; P; 30,5
Grootlichthoogte: -800mm
GROOT L: : 0,58; -0,16; P; 42,0
GROOT R: : -0,04; -0,19; P; 40,9
Mistlichthoogte: -800mm
MIST L: : 0,00; -5,06; F; 10,3
MIST R: : 0,00; -2,27; P; 10,4

```

Figure 74: Example of measurement results on ticket

Parameter	Description
Garage	Customer name.
Type	Model of Luminoscope®.
Serienummer	Serial number of the Luminoscope® optical block.
Datum, tijd	Date and time of the test.
Programma	Selected program.
Nummerplaat	License plate number of the vehicle.
Resultaten	<p>Arranged in columns with the following structure:</p> <ul style="list-style-type: none"> <li>• <b>L/R:</b> (Left/Right) horizontal beam position, expressed in the specified units.</li> <li>• <b>O/N:</b> (Up/Down) vertical beam position, expressed in the specified units.</li> <li>• <b>Status:</b> summarized result of the test, can be either <b>P</b> (Passed), or <b>F</b> (Failed).</li> <li>• <b>I:</b> (Intensity), expressed in kCd.</li> </ul>
Dimlichthoogte	Specified mounting height zone of the low beams.
Dim L	Measurement results of the left low beam in the specified units.
Dim R	Measurement results of the right low beam in the specified units.
Grootlichthoogte	Specified mounting height zone of the high beams.
Groot L	Measurement results of the left high beam in the specified units.
Groot R	Measurement results of the right high beam in the specified units.
Mistlichthoogte	Specified mounting height zone of the fog beams.
Mist L	Measurement results of the left fog beam in the specified units.
Mist R	Measurement results of the right fog beam in the specified units.

## 7.3 OEM test cycle sequences

The **OEM** button on the **Program selection** screen provides access to some special *Original Equipment Manufacturer* sequences for various beam types.

1. Tap on the **OEM** button 1 on the **Program selection** screen.




Figure 75: **Program selection** screen with **OEM** button

The **OEM program selection** screen is now displayed.

2. Select one of the options on the **OEM program selection** screen by tapping on the corresponding button.



**Remember:** The screen may have a different appearance depending on the customer's specific implementation.




Figure 76: **OEM program selection** screen

#	Button	Description
1	<b>ECE-VAR</b> button	Program selection for <i>ECE</i> low beam adjustment with <i>automatic calculation of the angle</i> of the cut-off line ( <b>ECE – variable</b> angle).
2	<b>ECE-15/45</b> button	Program selection for <i>ECE</i> low beam adjustment with <i>manual determination of the angle</i> of the cut-off line ( <b>ECE – 15° or 45°</b> angle).
3	<b>MDF</b> button	Program selection for <i>MDF (Maskiertes Dauerfernlicht)</i> high beam adjustment. An <i>MDF</i> high beam, is a glare free high beam with beam motorisation
4	<b>VOR</b> button	Program selection for <i>SAE VOR</i> low beam adjustment. This selection could be used to adjust <i>American VOR</i> low beams to be used in the Belgian traffic.
5	<b>VOL</b> button	Program selection for <i>SAE VOL</i> low beam adjustment. This selection could be used to adjust <i>American VOL</i> low beams to be used in the Belgian traffic.

#### Related tasks

[ECE-VAR low beam sequence](#) (pg. 100)

[ECE - 15°/45° low beam sequence](#) (pg. 105)

[MDF high beam sequence](#) (pg. 111)

[VOL American low beam sequence](#) (pg. 118)

[VOR American low beam sequence](#) (pg. 123)

### 7.3.1 ECE-VAR low beam sequence

This chapter explains the use of the OEM program selection for the adjustment of *ECE* low beams with *automatic calculation* of the angle of the *cut-off* line (**ECE – variable** angle).

**Note:** The *ECE-VAR* program could be used for low beams with a angle in a range of 10° till 50°. However, in most common cases the *ECE-15/45* program should be used instead of the *ECE-VAR* program.

Tap on the **ECE-VAR** button 1 on the **OEM program selection** screen.




Figure 77: **OEM program selection** screen with **ECE-VAR** button

The **Beam selection** screen for the *ECE-VAR* program is now displayed.




Figure 78: **Beam selection** screen for *ECE-VAR* program

#	Button	Description
1	First ECE low beam	Starts the test of the first ECE low beam.
2	First high beam	Starts the test of the first high beam.
3	First fog beam	Starts the test of the first fog beam.
4	Second ECE low beam	Starts the test of the second ECE low beam.
5	Second high beam	Starts the test of the second high beam.
6	Second fog beam	Starts the test of the second fog beam.
7	Program name	<i>ECE</i> program.



**Remember:** Rotating the screen position affects to the position of the beam icons and beam selection buttons on the screen. The intelligence of the Luminoscope® automatically places the beam icons and beam selection

buttons at the correct side of the vehicle. For both screen orientation modes, the beam icons and beam selection buttons which are closer to the left side of the vehicle are applicable for the headlamps on the left side. Those closer to the right side of the vehicle are applicable for the headlamps on the right side.

### Related information

[ECE or European low beam](#) (pg. 19)

[Left / right vehicle side definition](#) (pg. 60)

#### 7.3.1.1 Summary of the test sequence

What follows is a summarized listing of the steps for the test sequence. Refer to the next chapter for a detailed explanation of each step.

1. Align the Luminoscope® with the vehicle.
2. Tap on the beam selection button corresponding with the left or right *ECE* low beam.
3. Position the Luminoscope® sequentially in front of both *ECE* low beams.
4. Adjust both *ECE* low beams sequentially.

#### 7.3.1.2 Test sequence

1. Align the Luminoscope® with the vehicle.

Before the start of the actual test, the Luminoscope® should be properly aligned with the longitudinal axis (driving direction) of the vehicle. This is crucial in order to minimize the measurement result error in the horizontal direction. At the end of the chapter there is a link with related information on how to align the Luminoscope®.

**The next three steps are to be applied to both *ECE* low beams sequentially.**

2. Tap on the beam selection button corresponding with the left or right *ECE* low beam on the **Beam selection** screen to start its calibration.



**Remember:** Rotating the screen position affects to the position of the beam icons and beam selection buttons on the screen. The intelligence of the Luminoscope® automatically places the beam icons and beam selection buttons at the correct side of the vehicle. For both screen orientation modes, the beam icons and beam selection buttons which are closer to the left side of the vehicle are applicable for the headlamps on the left side. Those closer to the right side of the vehicle are applicable for the headlamps on the right side.

3. Position the Luminoscope® in front of the selected *ECE* low beam.

Make use of the electronic *Position Check* system.

Once the optimal position in front of the headlamp is achieved, the Luminoscope® proceeds automatically to the next phase in the test.

#### 4. Adjust the selected *ECE* low beam.

Both *ECE* low beams should be adjusted with exactly the same procedure.

**Note:** The *ECE* low beam algorithm is capable to determine the horizontal and vertical position of the *V-point* (also called *elbow point* or *kink point*) of the *cut-off line*. With this *ECE-VAR* program, the *ECE* low beam algorithm is also capable to determine the angle of the *ECE* low beam *cut-off line*.




Figure 79: Right *ECE* low beam adjustment

1	<i>Position Check Arrows</i>	Indicates the direction(s) on which the optical block should be moved to achieve the optimal position in front of the headlamp. This position can change when adjusting the headlamp.
2	Information field	Depending on the Luminoscope® configuration, some related information such as the name of the selected program (Vehicle), the name of the test (Beam), license plate, etc. will be displayed.
3	Live headlamp beam image	Real time image of the headlamp beam including overlays for tolerance zone(s), algorithm measurement position, etc.
4	<i>ECE</i> low beam icon	<i>ECE</i> low beam icon indicating the status of the beam. The meaning of the icon depends on its shape and color: <ul style="list-style-type: none"> <li>• <b>Yellow</b> mark means <b>Test in progress</b>.</li> <li>• <b>Green</b> V-sign means <b>In tolerance</b>.</li> <li>• <b>Red</b> cross means <b>Out of tolerance</b>.</li> </ul>
5	Information banner	The information banner shows different status messages such as: <b>Test in progress</b> , <b>Within tolerance</b> , <b>Out of tolerance</b> , etc. Status, error or warning messages can also be displayed over there.

6	<b>Rotate screen button</b>	Rotate the screen position.
7	<b>Validation button</b>	If the <i>live validation</i> function is activated, tapping on this button will store the beam measurement result. The result is unconditionally stored whether the algorithm measurement position is <i>Within tolerance</i> or <i>Out of tolerance</i> .
8	Audit tolerance zone	The <i>audit tolerance zone</i> allows the operator to check if the headlamp is within the audit tolerances that are applicable in a government inspection station.
9	Aiming tolerance zone	The aiming tolerance zone allows the operator to adjust the headlamp correctly. Note that the aiming tolerance zone should always be smaller than the audit tolerance zone. This is to ensure that a correctly aimed headlamp at a workshop ( <i>using the smaller aiming tolerance zone</i> ) will pass the test in a government inspection station ( <i>using the larger audit tolerance zone</i> ).
10	Algorithm measurement position	The algorithm overlay (red cross) represents the algorithm measurement position on the headlamp beam image. In case of an aiming cycle, the red cross position should be aimed towards the center of the aiming tolerance zone. In case of an audit cycle, the red cross position is evaluated. The actual position is displayed at the headlamp measurement result field.
11	Beam direction arrows	<p>The beam direction arrows indicate the direction(s) in which the headlamp should be moved to reach the target position inside the tolerance zone.</p> <p>The color of the arrows indicates the live status of the aiming:</p> <ul style="list-style-type: none"> <li>• <b>Green</b> means the result is <i>inside</i> the tolerance zone.</li> <li>• <b>Yellow</b> means the result is <i>close</i> to the tolerance zone.</li> <li>• <b>Red</b> means the result is <i>far away</i> from the tolerance zone.</li> </ul>
12	Headlamp measurement results field	Depending on the chosen algorithm and Luminoscope® configuration, headlamp measurement results such as horizontal beam position (X), vertical beam position (Y), headlamp mounting height (H), etc are displayed here.
13	ESL (Electronic Spirit Level) module angles	Measured Pitch and Roll angle of the ESL (Electronic Spirit Level) module, if applicable.
14	Cut-off angle field	The angle of the ECE low beam cut-off line is displayed here.

The following **Beam selection** screen is shown when both *ECE* low beams are properly adjusted.




Figure 80: **Beam selection** screen with ECE low beam test results



**Remember:** Rotating the screen position affects to the position of the beam icons and beam selection buttons on the screen. The intelligence of the Luminoscope® automatically places the beam icons and beam selection buttons at the correct side of the vehicle. For both screen orientation modes, the beam icons and beam selection buttons which are closer to the left side of the vehicle are applicable for the headlamps on the left side. Those closer to the right side of the vehicle are applicable for the headlamps on the right side.

### Related tasks

[Positioning in front of the headlamp](#) (pg. 77)

### Related information

[Alignment with the vehicle](#) (pg. 62)

[Low beam test](#) (pg. 80)

## 7.3.2 ECE - 15°/45° low beam sequence

This chapter explains the use of the OEM program selection for adjustment of ECE low beams with *manual determination* of the angle of the *cut-off line* (**ECE – 15° or 45°** angle).

**Note:** The **ECE-15/45** button has exactly the same functionality as the **Aiming** button (the *screwdriver* button) on the **Program selection** screen which was previously explained.

Tap on the **ECE-15/45** button 1 on the **OEM program selection** screen.



Figure 81: **OEM program selection** screen with **ECE-15/45** button

The **Beam selection** screen for the *ECE-15/45* program is now displayed.




Figure 82: **Beam selection** screen for *ECE-15/45* program

#	Button	Description
1	First ECE low beam	Starts the test of the first ECE low beam.
2	First high beam	Starts the test of the first high beam.
3	First fog beam	Starts the test of the first fog beam.
4	Second ECE low beam	Starts the test of the second ECE low beam.
5	Second high beam	Starts the test of the second high beam.
6	Second fog beam	Starts the test of the second fog beam.
7	Program name	<i>ECE LHD Fix</i> program.



**Remember:** Rotating the screen position affects to the position of the beam icons and beam selection buttons on the screen. The intelligence of the Luminoscope® automatically places the beam icons and beam selection

buttons at the correct side of the vehicle. For both screen orientation modes, the beam icons and beam selection buttons which are closer to the left side of the vehicle are applicable for the headlamps on the left side. Those closer to the right side of the vehicle are applicable for the headlamps on the right side.

### Related information

[ECE or European low beam](#) (pg. 19)

[Left / right vehicle side definition](#) (pg. 60)

### 7.3.2.1 Summary of the test sequence

What follows is a summarized listing of the steps for the test sequence. Refer to the next chapter for a detailed explanation of each step.

1. Align the Luminoscope® with the vehicle.
2. Tap on the beam selection button corresponding with the left or right *ECE* low beam.
3. Position the Luminoscope® sequentially in front of both *ECE* low beams.
4. Adjust both *ECE* low beams sequentially.

### 7.3.2.2 Test sequence

1. Align the Luminoscope® with the vehicle.

Before the start of the actual test, the Luminoscope® should be properly aligned with the longitudinal axis (driving direction) of the vehicle. This is crucial in order to minimize the measurement result error in the horizontal direction. At the end of the chapter there is a link with related information on how to align the Luminoscope®.

**The next three steps are to be applied to both *ECE* low beams sequentially.**

2. Tap on the beam selection button corresponding with the left or right *ECE* low beam on the **Beam selection** screen to start its calibration.



**Remember:** Rotating the screen position affects to the position of the beam icons and beam selection buttons on the screen. The intelligence of the Luminoscope® automatically places the beam icons and beam selection buttons at the correct side of the vehicle. For both screen orientation modes, the beam icons and beam selection buttons which are closer to the left side of the vehicle are applicable for the headlamps on the left side. Those closer to the right side of the vehicle are applicable for the headlamps on the right side.

3. Position the Luminoscope® in front of the selected *ECE* low beam.

Make use of the electronic *Position Check* system.

Once the optimal position in front of the headlamp is achieved, the Luminoscope® proceeds automatically to the next phase in the test.

#### 4. Adjust the selected *ECE* low beam.

Both *ECE* low beams should be adjusted with exactly the same procedure.

**Note:** The *ECE* low beam algorithm is capable to determine the horizontal and vertical position of the *V-point* (also called *elbow point* or *kink point*) of the *cut-off line*. Each time the **Cut-off angle** button is tapped, the selected angle of the low beam tolerance overlay changes between 15° and 45°. In most common cases the default selection of 15° can be used. Use the 45° selection only for *ECE* low beam *cut-off* lines with a 45° step. It is important to correctly set the angle because it has a direct consequence on the horizontal algorithm measurement position (determination of the *V-point*) of the *cut-off* line.

In case of an *ECE LHD* (Left Hand Drive) low beam with a 15° angle:




Figure 83: Right *ECE* low beam with 15° angle adjustment

In case of an *ECE LHD* (Left Hand Drive) low beam with a 45° angle:




Figure 84: Right ECE low beam with 45° angle adjustment

1	Position Check Arrows	Indicates the direction(s) on which the optical block should be moved to achieve the optimal position in front of the headlamp. This position can change when adjusting the headlamp.
2	Information field	Depending on the Luminoscope® configuration, some related information such as the name of the selected program (Vehicle), the name of the test (Beam), license plate, etc. will be displayed.
3	Live headlamp beam image	Real time image of the headlamp beam including overlays for tolerance zone(s), algorithm measurement position, etc.
4	ECE low beam icon	ECE low beam icon indicating the status of the beam. The meaning of the icon depends on its shape and color: <ul style="list-style-type: none"> <li>• <b>Yellow</b> mark means <b>Test in progress</b>.</li> <li>• <b>Green</b> V-sign means <b>In tolerance</b>.</li> <li>• <b>Red</b> cross means <b>Out of tolerance</b>.</li> </ul>
5	Information banner	The information banner shows different status messages such as: <b>Test in progress</b> , <b>Within tolerance</b> , <b>Out of tolerance</b> , etc. Status, error or warning messages can also be displayed over there.
6	Rotate screen button	Rotate the screen position.
7	Validation button	If the <i>live validation</i> function is activated, tapping on this button will store the beam measurement result. The result is unconditionally stored whether the algorithm measurement position is <i>Within tolerance</i> or <i>Out of tolerance</i> .
8	Audit tolerance zone	The <i>audit tolerance zone</i> allows the operator to check if the headlamp is within the audit tolerances that are applicable in a government inspection station.

9	Aiming tolerance zone	The aiming tolerance zone allows the operator to adjust the headlamp correctly. Note that the aiming tolerance zone should always be smaller than the audit tolerance zone. This is to ensure that a correctly aimed headlamp at a workshop ( <i>using the smaller aiming tolerance zone</i> ) will pass the test in a government inspection station ( <i>using the larger audit tolerance zone</i> ).
10	Algorithm measurement position	The algorithm overlay (red cross) represents the algorithm measurement position on the headlamp beam image. In case of an aiming cycle, the red cross position should be aimed towards the center of the aiming tolerance zone. In case of an audit cycle, the red cross position is evaluated. The actual position is displayed at the headlamp measurement result field.
11	Beam direction arrows	<p>The beam direction arrows indicate the direction(s) in which the headlamp should be moved to reach the target position inside the tolerance zone.</p> <p>The color of the arrows indicates the live status of the aiming:</p> <ul style="list-style-type: none"> <li>• <b>Green</b> means the result is <i>inside</i> the tolerance zone.</li> <li>• <b>Yellow</b> means the result is <i>close</i> to the tolerance zone.</li> <li>• <b>Red</b> means the result is <i>far away</i> from the tolerance zone.</li> </ul>
12	Headlamp measurement results field	Depending on the chosen algorithm and Luminoscope® configuration, headlamp measurement results such as horizontal beam position (X), vertical beam position (Y), headlamp mounting height (H), etc are displayed here.
13	ESL (Electronic Spirit Level) module angles	Measured Pitch and Roll angle of the ESL (Electronic Spirit Level) module, if applicable.
14	Cut-off angle field	The angle of the ECE low beam cut-off line is displayed here.
15	Cut-off angle button	Each time the <b>Cut-off angle</b> button is tapped, the selected angle of the low beam tolerance overlay changes between 15° and 45°. In most common cases the default selection of 15° can be used. Use the 45° selection only for ECE low beam cut-off lines with a 45° step. It is important to correctly set the angle because it has a direct consequence on the horizontal algorithm measurement position (determination of the <i>V-point</i> ) of the cut-off line.

The following **Beam selection** screen is shown when both ECE low beams are properly adjusted.




Figure 85: **Beam selection** screen with ECE low beam test results



**Remember:** Rotating the screen position affects to the position of the beam icons and beam selection buttons on the screen. The intelligence of the Luminoscope® automatically places the beam icons and beam selection buttons at the correct side of the vehicle. For both screen orientation modes, the beam icons and beam selection buttons which are closer to the left side of the vehicle are applicable for the headlamps on the left side. Those closer to the right side of the vehicle are applicable for the headlamps on the right side.

### Related tasks

[Positioning in front of the headlamp](#) (pg. 77)

### Related information

[Alignment with the vehicle](#) (pg. 62)

[Low beam test](#) (pg. 80)

## 7.3.3 MDF high beam sequence

This chapter explains the use of the OEM program selection for *MDF* high beam adjustment. An *MDF* high beam, is a glare free high beam with motorization.

**Note:** This specific *MDF* selection is only applicable to vehicles which have this function available.



**Remember:** To perform the *MDF* high beam calibration, most of the vehicles need to be set in a special calibration mode to reveal the *MDF* pattern. A *vehicle diagnostic tester* must be connected to the *On Board Diagnostic (OBD)* port of the vehicle to switch the *MDF* high beams in a special calibration mode.

Refer to the specific instructions from the vehicle manufacturer in the vehicle manual.

**Note:** The *MDF* high beam has to be physically adjusted with the headlamp adjustment screws.  
Tap on the **MDF** button 1 on the **OEM program selection** screen.




Figure 86: **OEM program selection** screen with **MDF** button

The **Beam selection** screen for the *MDF* program is now displayed.




Figure 87: **Beam selection** screen for *MDF* program

#	Button	Description
1	First low beam	Starts the test of the first low beam.
2	First <i>MDF</i> high beam	Starts the test of the first <i>MDF</i> high beam.
3	First fog beam	Starts the test of the first fog beam.
4	Second low beam	Starts the test of the second low beam.
5	Second <i>MDF</i> high beam	Starts the test of the second <i>MDF</i> high beam.
6	Second fog beam	Starts the test of the second fog beam.
7	Program name	<i>MDF</i> program.



**Remember:** Rotating the screen position affects to the position of the beam icons and beam selection buttons on the screen. The intelligence of the Luminoscope® automatically places the beam icons and beam selection buttons at the correct side of the vehicle. For both screen orientation modes, the beam icons and beam selection buttons which are closer to the left side of the vehicle are applicable for the headlamps on the left side. Those closer to the right side of the vehicle are applicable for the headlamps on the right side.

**Note:** The low and fog beam buttons on the **Beam selection** screen remain disabled until both *MDF* high beams are properly adjusted.

### Related information

[Glare free high beam with beam motorisation](#) (pg. 24)

[Left / right vehicle side definition](#) (pg. 60)

#### 7.3.3.1 Summary of the test sequence

What follows is a summarized listing of the steps for the test sequence. Refer to the next chapter for a detailed explanation of each step.

1. Align the Luminoscope® with the vehicle.
2. Switch the high beams to *MDF* mode.
3. Tap on the beam selection button corresponding with the left or right *MDF* high beam.
4. Position the Luminoscope® sequentially in front of both *MDF* high beams.
5. Adjust both *MDF* high beams sequentially.
6. Switch on the low beams.
7. Tap on the beam selection button corresponding with the left or right low beam.
8. Position the Luminoscope® sequentially in front of both low beams.
9. Adjust both low beams sequentially in vertical direction only.

#### 7.3.3.2 Test sequence

1. Align the Luminoscope® with the vehicle.  
Before the start of the actual test, the Luminoscope® should be properly aligned with the longitudinal axis (driving direction) of the vehicle. This is crucial in order to minimize the measurement result error in the horizontal direction. At the end of the chapter there is a link with related information on how to align the Luminoscope®.
2. Switch the high beams to *MDF* mode.

To perform the *MDF* high beam calibration, most of the vehicles need to be set in a special calibration mode to reveal the *MDF* high beam pattern.

Refer to the specific instructions from the vehicle manufacturer in the vehicle manual.

**The next three steps are to be applied to both *MDF* high beams sequentially.**

3. Tap on the beam selection button corresponding with the left or right *MDF* high beam on the **Beam selection** screen to start its calibration.



**Remember:** Rotating the screen position affects to the position of the beam icons and beam selection buttons on the screen. The intelligence of the Luminoscope® automatically places the beam icons and beam selection buttons at the correct side of the vehicle. For both screen orientation modes, the beam icons and beam selection buttons which are closer to the left side of the vehicle are applicable for the headlamps on the left side. Those closer to the right side of the vehicle are applicable for the headlamps on the right side.

4. Position the Luminoscope® in front of the selected *MDF* high beam.

Make use of the electronic *Position Check* system.

Once the optimal position in front of the headlamp is achieved, the Luminoscope® proceeds automatically to the next phase in the test.

5. Adjust the selected *MDF* high beam.

Both *MDF* high beams should be adjusted towards the tolerance zone in horizontal direction (X direction) and vertical direction (Y direction).

The projection of the left and right *MDF* high beams differ from each other.

**Note:** The *MDF* high beam algorithm is capable to determine the *kink* point on the lower horizontal line of the *MDF* high beam *cut-off* line. The *MDF* high beam *cut-off* line has a 90° step.




Figure 88: Left *MDF* high beam adjustment




Figure 89: Right MDF high beam adjustment

1	Position Check Arrows	Indicates the direction(s) on which the optical block should be moved to achieve the optimal position in front of the headlamp. This position can change when adjusting the headlamp.
2	Information field	Depending on the Luminoscope® configuration, some related information such as the name of the selected program (Vehicle), the name of the test (Beam), license plate, etc. will be displayed.
3	Live headlamp beam image	Real time image of the headlamp beam including overlays for tolerance zone(s), algorithm measurement position, etc.
4	MDF high beam icon	<p>MDF high beam icon indicating the status of the beam.</p> <p>The meaning of the icon depends on its shape and color:</p> <ul style="list-style-type: none"> <li>• <b>Yellow</b> mark means <b>Test in progress</b>.</li> <li>• <b>Green</b> V-sign means <b>In tolerance</b>.</li> <li>• <b>Red</b> cross means <b>Out of tolerance</b>.</li> </ul>
5	Information banner	The information banner shows different status messages such as: <b>Test in progress</b> , <b>Within tolerance</b> , <b>Out of tolerance</b> , etc. Status, error or warning messages can also be displayed over there.
6	Rotate screen button	Rotate the screen position.
7	Validation button	If the <i>live validation</i> function is activated, tapping on this button will store the beam measurement result. The result is unconditionally stored whether the algorithm measurement position is <i>Within tolerance</i> or <i>Out of tolerance</i> .

8	Algorithm measurement position	The algorithm overlay (red cross) represents the algorithm measurement position on the headlamp beam image. In case of an aiming cycle, the red cross position should be aimed towards the center of the aiming tolerance zone. In case of an audit cycle, the red cross position is evaluated. The actual position is displayed at the headlamp measurement result field.
9	Aiming tolerance zone	The aiming tolerance zone allows the operator to adjust the headlamp correctly. Note that the aiming tolerance zone should always be smaller than the audit tolerance zone. This is to ensure that a correctly aimed headlamp at a workshop ( <i>using the smaller aiming tolerance zone</i> ) will pass the test in a government inspection station ( <i>using the larger audit tolerance zone</i> ).
10	Beam direction arrows	<p>The beam direction arrows indicate the direction(s) in which the headlamp should be moved to reach the target position inside the tolerance zone.</p> <p>The color of the arrows indicates the live status of the aiming:</p> <ul style="list-style-type: none"> <li>• <b>Green</b> means the result is <i>inside</i> the tolerance zone.</li> <li>• <b>Yellow</b> means the result is <i>close</i> to the tolerance zone.</li> <li>• <b>Red</b> means the result is <i>far away</i> from the tolerance zone.</li> </ul>
11	Headlamp measurement results field	Depending on the chosen algorithm and Luminoscope® configuration, headlamp measurement results such as horizontal beam position (X), vertical beam position (Y), headlamp mounting height (H), etc are displayed here.
12	ESL (Electronic Spirit Level) module angles	Measured Pitch and Roll angle of the ESL (Electronic Spirit Level) module, if applicable.

The following **Beam selection** screen is shown when both *MDF* high beams are properly adjusted.




Figure 90: **Beam selection** screen with MDF high beam test results



**Remember:** Rotating the screen position affects to the position of the beam icons and beam selection buttons on the screen. The intelligence of the Luminoscope® automatically places the beam icons and beam selection buttons at the correct side of the vehicle. For both screen orientation modes, the beam icons and beam selection buttons which are closer to the left side of the vehicle are applicable for the headlamps on the left side. Those closer to the right side of the vehicle are applicable for the headlamps on the right side.

**6. Switch on the low beams.**

Refer to the specific instructions from the vehicle manufacturer in the vehicle manual.

**The next three steps are to be applied to both low beams sequentially.**

**7. Tap on the beam selection button corresponding with the left or right low beam on the **Beam selection** screen to start its calibration.**



**Remember:** Rotating the screen position affects to the position of the beam icons and beam selection buttons on the screen. The intelligence of the Luminoscope® automatically places the beam icons and beam selection buttons at the correct side of the vehicle. For both screen orientation modes, the beam icons and beam selection buttons which are closer to the left side of the vehicle are applicable for the headlamps on the left side. Those closer to the right side of the vehicle are applicable for the headlamps on the right side.

**8. Position the Luminoscope® in front of the selected low beam.**

Make use of the electronic *Position Check* system.

Once the optimal position in front of the headlamp is achieved, the Luminoscope® proceeds automatically to the next phase in the test.

**9.** Adjust the selected low beam in vertical direction only.

Both low beams should be adjusted towards the tolerance zone in vertical direction (Y direction) only.



**CAUTION:** It is not allowed to adjust the horizontal direction (X direction) of the low beams as this has a direct influence on the previously performed calibration of the *MDF* high beams.

**Note:** The *ECE* low beam algorithm is capable to determine the horizontal and vertical position of the *V-point* (also called *elbow point* or *kink point*) of the *cut-off line*.

**Related tasks**

[Positioning in front of the headlamp](#) (pg. 77)

**Related information**

[Alignment with the vehicle](#) (pg. 62)

[Low beam test](#) (pg. 80)

### 7.3.4 VOL American low beam sequence

This chapter explains the use of the OEM program selection for adjustment of American VOL low beams to be used in the Belgian traffic.

**Note:** This specific *SAE VOL* selection is only applicable to vehicles which are equipped with American VOL low beams.

Tap on the **VOL** button 1 on the **OEM program selection** screen.




Figure 91: **OEM program selection** screen with **VOL** button

The **Beam selection** screen for the *VOL* program is now displayed.




Figure 92: **Beam selection** screen for VOL program

#	Button	Description
1	First VOL low beam	Starts the test of the first VOL low beam.
2	First high beam	Starts the test of the first high beam.
3	First fog beam	Starts the test of the first fog beam.
4	Second VOL low beam	Starts the test of the second VOL low beam.
5	Second high beam	Starts the test of the second high beam.
6	Second fog beam	Starts the test of the second fog beam.
7	Program name	VOL program.



**Remember:** Rotating the screen position affects to the position of the beam icons and beam selection buttons on the screen. The intelligence of the Luminoscope® automatically places the beam icons and beam selection buttons at the correct side of the vehicle. For both screen orientation modes, the beam icons and beam selection buttons which are closer to the left side of the vehicle are applicable for the headlamps on the left side. Those closer to the right side of the vehicle are applicable for the headlamps on the right side.

#### Related information

[SAE or American low beam](#) (pg. 22)

[Left / right vehicle side definition](#) (pg. 60)

#### 7.3.4.1 Summary of the test sequence

What follows is a summarized listing of the steps for the test sequence. Refer to the next chapter for a detailed explanation of each step.

1. Align the Luminoscope® with the vehicle.

2. Tap on the beam selection button corresponding with the left or right *VOL* low beam.
3. Position the Luminoscope® sequentially in front of both *VOL* low beams.
4. Adjust both *VOL* low beams sequentially.

#### 7.3.4.2 Test sequence

1. Align the Luminoscope® with the vehicle.

Before the start of the actual test, the Luminoscope® should be properly aligned with the longitudinal axis (driving direction) of the vehicle. This is crucial in order to minimize the measurement result error in the horizontal direction. At the end of the chapter there is a link with related information on how to align the Luminoscope®.

**The next three steps are to be applied to both *VOL* low beams sequentially.**

2. Tap on the beam selection button corresponding with the left or right *VOL* low beam on the **Beam selection** screen to start its calibration.



**Remember:** Rotating the screen position affects to the position of the beam icons and beam selection buttons on the screen. The intelligence of the Luminoscope® automatically places the beam icons and beam selection buttons at the correct side of the vehicle. For both screen orientation modes, the beam icons and beam selection buttons which are closer to the left side of the vehicle are applicable for the headlamps on the left side. Those closer to the right side of the vehicle are applicable for the headlamps on the right side.

3. Position the Luminoscope® in front of the selected *VOL* low beam.

Make use of the electronic *Position Check* system.

Once the optimal position in front of the headlamp is achieved, the Luminoscope® proceeds automatically to the next phase in the test.

4. Adjust the selected *VOL* low beam.

Both *VOL* low beams should be adjusted with exactly the same procedure.

**Note:** The *VOL* low beam algorithm is capable to determine the required vertical position of the *VOL* low beam *cut-off* line.

The vertical position of the *cut-off* line is measured at 4,35% (2,5°) to the left of the absolute zero reference point of the Luminoscope®.

**Note:** The headlamp should only be adjusted in vertical direction (Y direction). The vertical *cut-off* position should be set to -1,25% to be used in Belgian traffic.




Figure 93: Right VOL low beam adjustment

1	<i>Position Check Arrows</i>	Indicates the direction(s) on which the optical block should be moved to achieve the optimal position in front of the headlamp. This position can change when adjusting the headlamp.
2	Information field	Depending on the Luminoscope® configuration, some related information such as the name of the selected program (Vehicle), the name of the test (Beam), license plate, etc. will be displayed.
3	Live headlamp beam image	Real time image of the headlamp beam including overlays for tolerance zone(s), algorithm measurement position, etc.
4	VOL low beam icon	VOL low beam icon indicating the status of the beam. The meaning of the icon depends on its shape and color: <ul style="list-style-type: none"> <li>• <b>Yellow</b> mark means <b>Test in progress</b>.</li> <li>• <b>Green</b> V-sign means <b>In tolerance</b>.</li> <li>• <b>Red</b> cross means <b>Out of tolerance</b>.</li> </ul>
5	Information banner	The information banner shows different status messages such as: <b>Test in progress</b> , <b>Within tolerance</b> , <b>Out of tolerance</b> , etc. Status, error or warning messages can also be displayed over there.
6	<b>Rotate screen</b> button	Rotate the screen position.
7	<b>Validation</b> button	If the <i>live validation</i> function is activated, tapping on this button will store the beam measurement result. The result is unconditionally stored whether the algorithm measurement position is <i>Within tolerance</i> or <i>Out of tolerance</i> .

8	Aiming tolerance zone	The aiming tolerance zone allows the operator to adjust the headlamp correctly. Note that the aiming tolerance zone should always be smaller than the audit tolerance zone. This is to ensure that a correctly aimed headlamp at a workshop ( <i>using the smaller aiming tolerance zone</i> ) will pass the test in a government inspection station ( <i>using the larger audit tolerance zone</i> ).
9	Algorithm measurement position	The algorithm overlay (red cross) represents the algorithm measurement position on the headlamp beam image. In case of an aiming cycle, the red cross position should be aimed towards the center of the aiming tolerance zone. In case of an audit cycle, the red cross position is evaluated. The actual position is displayed at the headlamp measurement result field.
10	Beam direction arrows	<p>The beam direction arrows indicate the direction(s) in which the headlamp should be moved to reach the target position inside the tolerance zone.</p> <p>The color of the arrows indicates the live status of the aiming:</p> <ul style="list-style-type: none"> <li>• <b>Green</b> means the result is <i>inside</i> the tolerance zone.</li> <li>• <b>Yellow</b> means the result is <i>close</i> to the tolerance zone.</li> <li>• <b>Red</b> means the result is <i>far away</i> from the tolerance zone.</li> </ul>
11	Headlamp measurement results field	Depending on the chosen algorithm and Luminoscope® configuration, headlamp measurement results such as horizontal beam position (X), vertical beam position (Y), headlamp mounting height (H), etc are displayed here.
12	ESL (Electronic Spirit Level) module angles	Measured Pitch and Roll angle of the ESL (Electronic Spirit Level) module, if applicable.

The following **Beam selection** screen is shown when both *VOL* low beams are properly adjusted.




Figure 94: **Beam selection** screen with SAE VOL low beam test results



**Remember:** Rotating the screen position affects to the position of the beam icons and beam selection buttons on the screen. The intelligence of the Luminoscope® automatically places the beam icons and beam selection buttons at the correct side of the vehicle. For both screen orientation modes, the beam icons and beam selection buttons which are closer to the left side of the vehicle are applicable for the headlamps on the left side. Those closer to the right side of the vehicle are applicable for the headlamps on the right side.

#### Related tasks

[Positioning in front of the headlamp](#) (pg. 77)

#### Related information

[Alignment with the vehicle](#) (pg. 62)

### 7.3.5 VOR American low beam sequence

This chapter explains the use of the OEM program selection for adjustment of American VOR low beams to be used in the Belgian traffic.

**Note:** This specific SAE VOR selection is only applicable to vehicles which are equipped with American VOR low beams.

Tap on the **VOR** button 1 on the **OEM program selection** screen.




Figure 95: **OEM program selection** screen with **VOR** button

The **Beam selection** screen for the **VOR** program is now displayed.




Figure 96: **Beam selection** screen for **VOR** program

#	Button	Description
1	First VOR low beam	Starts the test of the first VOR low beam.
2	First high beam	Starts the test of the first high beam.
3	First fog beam	Starts the test of the first fog beam.
4	Second VOR low beam	Starts the test of the second VOR low beam.
5	Second high beam	Starts the test of the second high beam.
6	Second fog beam	Starts the test of the second fog beam.
7	Program name	VOR program.



**Remember:** Rotating the screen position affects to the position of the beam icons and beam selection buttons on the screen. The intelligence of the Luminoscope® automatically places the beam icons and beam selection

buttons at the correct side of the vehicle. For both screen orientation modes, the beam icons and beam selection buttons which are closer to the left side of the vehicle are applicable for the headlamps on the left side. Those closer to the right side of the vehicle are applicable for the headlamps on the right side.

#### Related information

[SAE or American low beam](#) (pg. 22)

[Left / right vehicle side definition](#) (pg. 60)

#### 7.3.5.1 Summary of the test sequence

What follows is a summarized listing of the steps for the test sequence. Refer to the next chapter for a detailed explanation of each step.

1. Align the Luminoscope® with the vehicle.
2. Tap on the beam selection button corresponding with the left or right *VOR* low beam.
3. Position the Luminoscope® sequentially in front of both *VOR* low beams.
4. Adjust both *VOR* low beams sequentially.

#### 7.3.5.2 Test sequence

1. Align the Luminoscope® with the vehicle.

Before the start of the actual test, the Luminoscope® should be properly aligned with the longitudinal axis (driving direction) of the vehicle. This is crucial in order to minimize the measurement result error in the horizontal direction. At the end of the chapter there is a link with related information on how to align the Luminoscope®.

**The next three steps are to be applied to both *VOR* low beams sequentially.**

2. Tap on the beam selection button corresponding with the left or right *VOR* low beam on the **Beam selection** screen to start its calibration.



**Remember:** Rotating the screen position affects to the position of the beam icons and beam selection buttons on the screen. The intelligence of the Luminoscope® automatically places the beam icons and beam selection buttons at the correct side of the vehicle. For both screen orientation modes, the beam icons and beam selection buttons which are closer to the left side of the vehicle are applicable for the headlamps on the left side. Those closer to the right side of the vehicle are applicable for the headlamps on the right side.

3. Position the Luminoscope® in front of the selected *VOR* low beam.

Make use of the electronic *Position Check* system.

Once the optimal position in front of the headlamp is achieved, the Luminoscope® proceeds automatically to the next phase in the test.

#### 4. Adjust the selected VOR low beam.

Both VOR low beams should be adjusted with exactly the same procedure.

**Note:** The VOR low beam algorithm is capable to determine the required vertical position of the VOR low beam *cut-off* line.

The vertical position of the *cut-off* line is measured at 3,50% (2,0°) to the right of the absolute zero reference point of the Luminoscope®.

**Note:** The headlamp should only be adjusted in vertical direction (Y direction). The vertical *cut-off* position should be set to -0,5% to be used in Belgian traffic.




Figure 97: Right VOR low beam adjustment

1	<i>Position Check Arrows</i>	Indicates the direction(s) on which the optical block should be moved to achieve the optimal position in front of the headlamp. This position can change when adjusting the headlamp.
2	Information field	Depending on the Luminoscope® configuration, some related information such as the name of the selected program (Vehicle), the name of the test (Beam), license plate, etc. will be displayed.
3	Live headlamp beam image	Real time image of the headlamp beam including overlays for tolerance zone(s), algorithm measurement position, etc.
4	VOR low beam icon	VOR low beam icon indicating the status of the beam. The meaning of the icon depends on its shape and color: <ul style="list-style-type: none"> <li>• <b>Yellow</b> mark means <b>Test in progress</b>.</li> <li>• <b>Green</b> V-sign means <b>In tolerance</b>.</li> <li>• <b>Red</b> cross means <b>Out of tolerance</b>.</li> </ul>

5	Information banner	The information banner shows different status messages such as: <b>Test in progress</b> , <b>Within tolerance</b> , <b>Out of tolerance</b> , etc. Status, error or warning messages can also be displayed over there.
6	<b>Rotate screen</b> button	Rotate the screen position.
7	<b>Validation</b> button	If the <i>live validation</i> function is activated, tapping on this button will store the beam measurement result. The result is unconditionally stored whether the algorithm measurement position is <i>Within tolerance</i> or <i>Out of tolerance</i> .
8	Aiming tolerance zone	The aiming tolerance zone allows the operator to adjust the headlamp correctly. Note that the aiming tolerance zone should always be smaller than the audit tolerance zone. This is to ensure that a correctly aimed headlamp at a workshop ( <i>using the smaller aiming tolerance zone</i> ) will pass the test in a government inspection station ( <i>using the larger audit tolerance zone</i> ).
9	Algorithm measurement position	The algorithm overlay (red cross) represents the algorithm measurement position on the headlamp beam image. In case of an aiming cycle, the red cross position should be aimed towards the center of the aiming tolerance zone. In case of an audit cycle, the red cross position is evaluated. The actual position is displayed at the headlamp measurement result field.
10	Beam direction arrows	<p>The beam direction arrows indicate the direction(s) in which the headlamp should be moved to reach the target position inside the tolerance zone.</p> <p>The color of the arrows indicates the live status of the aiming:</p> <ul style="list-style-type: none"> <li>• <b>Green</b> means the result is <i>inside</i> the tolerance zone.</li> <li>• <b>Yellow</b> means the result is <i>close</i> to the tolerance zone.</li> <li>• <b>Red</b> means the result is <i>far away</i> from the tolerance zone.</li> </ul>
11	Headlamp measurement results field	Depending on the chosen algorithm and Luminoscope® configuration, headlamp measurement results such as horizontal beam position (X), vertical beam position (Y), headlamp mounting height (H), etc are displayed here.
12	ESL (Electronic Spirit Level) module angles	Measured Pitch and Roll angle of the ESL (Electronic Spirit Level) module, if applicable.

The following **Beam selection** screen is shown when both *VOR* low beams are properly adjusted.




Figure 98: **Beam selection** screen with SAE VOR low beam test results



**Remember:** Rotating the screen position affects to the position of the beam icons and beam selection buttons on the screen. The intelligence of the Luminoscope® automatically places the beam icons and beam selection buttons at the correct side of the vehicle. For both screen orientation modes, the beam icons and beam selection buttons which are closer to the left side of the vehicle are applicable for the headlamps on the left side. Those closer to the right side of the vehicle are applicable for the headlamps on the right side.

#### Related tasks

[Positioning in front of the headlamp \(pg. 77\)](#)

#### Related information

[Alignment with the vehicle \(pg. 62\)](#)

---

# 8 Navigation map


---

This navigation map shows the most important screens on the Luminoscope® system and how to get there, including a reference to the corresponding chapter in the manual.

## Program selection screen



**Remember:** The screen may have a different appearance depending on the customer's specific implementation.



The **Program selection** screen is displayed after starting up the system and offers different programs. This allows the operator to select a preconfigured test cycle sequence. There's also a **System** button to access the **System** screen.




Tap on the button above to enter the **System** screen.

### Related tasks

[Program selection screen \(pg. 73\)](#)


## System screen



The **System** screen displays different system items.




Tap on the button above to enter the **Setup login** screen.


**Related tasks****System** screen (pg. 133)**Setup login screen**

The **Setup login** screen allows the operator to enter the **Setup** screen.

Enter your credentials and tap on the **Validation** button.

**Setup screen**

**Remember:** The access rights to the different menus on the screen are hierarchical and depend on the applied login level, which is password protected.



The **Setup** screen allows the operator to enter the **Computer configuration** screen **A**, **Settings program** screen **B**, **Verification** screen **C**, **Calibration** screen **D** and the **Power** screen.

Tap on the **A** button above to enter the **Computer configuration** screen.

Tap on the **B** button above to enter the **Settings program** screen.

Tap on the **C** button above to enter the **Verification** screen.


Tap on the **D** button above to enter the **Calibration** screen.

**Related tasks**

[Setup screen](#) (pg. 155)

**Computer configuration screen**

**Remember:** The screen may have a different appearance depending on the customer's specific implementation. The access rights to the different menus on the screen are hierarchical and depend on the applied login level, which is password protected.




The **Computer configuration** screen allows the operator to access date/time settings, licensing information and communication related parameters.

**Related tasks**

[Computer configuration screen](#) (pg. 161)

**Settings program screen**

**Remember:** The screen may have a different appearance depending on the customer's specific implementation. The access rights to the different menus on the screen are hierarchical and depend on the applied login level, which is password protected.





The **Settings program** screen allows the operator to edit the Luminoscope® databases. The settings program contains a collection of parameters used in the Luminoscope®. These parameters define the vehicles (also called programs), headlamps (also called tests), components and users.

## Verification screen



**Remember:** The screen may have a different appearance depending on the customer's specific implementation. The access rights to the different menus on the screen are hierarchical and depend on the applied login level, which is password protected.





The **Verification** screen allows the operator to access tools for verification of the calibration and operations of the Luminoscope®.

## Calibration screen



**Remember:** The screen may have a different appearance depending on the customer's specific implementation. The access rights to the different menus on the screen are hierarchical and depend on the applied login level, which is password protected.



The **Calibration** screen allows the operator to access tools for calibration of different components of the Luminoscope®.

# 9 System screen

The **System** screen acts as a hub for a number of functions. Among others, it gives access to the following functions which are thoroughly explained in the upcoming chapters:

- Turn off or restart the Luminoscope®.
- Language selection.
- Setup menu.
- Overview of technical data of the Luminoscope®.
- Reprint the last test result.
- Recall the recent test results.
- Data import and export using a *USB* stick.

When powered-up, the Luminoscope® displays the **Program selection** screen. Follow the navigation sequence below to reach the **System** screen.

1. Tap on the **System** button 1 on the **Program selection** screen.




**Remember:** The screen may have a different appearance depending on the customer's specific implementation.



Figure 99: **Program selection** screen with **System** button

The **System** screen is now displayed.

2. Choose one of the options on the **System** screen and tap on the corresponding button.

Figure 100: **System** screen

#	Button	Description
2	<b>Power</b> button	Turn off or restart the Luminoscope®
3	<b>Language</b> button	Select the language for the user interface.
4	<b>Setup</b> button	Enter the <b>Setup login</b> screen.
5	<b>Test program</b> button	Enter the <b>Beam selection</b> screen to execute a test cycle without communication (if applicable).
6	<b>System information</b> button	Overview of technical data of the Luminoscope®.
7	<b>Print last result</b> button	Reprint the last test result.
8	<b>Recall recent results</b> button	Query the most recent test results and reprint if needed.
9	<b>Abort</b> button	Return to the <b>Program selection</b> screen.
10	<b>USB</b> button	Import/export data using a USB stick.

**Tip:**

- Button 7 is only functional when a ticket printer is connected to the Luminoscope®.
- The **USB** button 10 appears when an **USB** stick is inserted in the connector plate of the Luminoscope®.

## 9.1 Luminoscope® turn off or restart

The **Power** button on the **System** screen gives access to the menu to turn off or restart the Luminoscope®.

1. Tap on the **Power** button 1 on the **System** screen.




Figure 101: **System** screen with **Power** button

The **Power** screen is now displayed.

2. Choose one of the options on the **Power** screen and tap on the corresponding button.




Figure 102: **Power** screen

#	Button	Description
2	<b>Restart</b> button	Restart the Luminoscope®.
3	<b>Turn Off</b> button	Turn off the Luminoscope®.
4	<b>System</b> button	Access the <b>System</b> screen.
5	<b>Abort</b> button	Return to the <b>Program selection</b> screen.

**Related information**[Power management](#) (pg. 55)

## 9.2 Language selection

The **Language** button on the **System** screen gives access to the menu to choose the language of the user interface of the Luminoscope®.

1. Tap on the **Language** button 1 on the **System** screen.




Figure 103: **System** screen with **Language** button

The **Language selection** screen is now displayed.

2. Choose one of the options on the **Language selection** screen and tap on the corresponding button.



**Remember:** The screen may have a different appearance depending on the customer's specific implementation.




Figure 104: **Language selection** screen

#	Button	Description
2	<b>Language selection</b> button	Select a language for the user interface.
3	<b>Abort</b> button	Return to the <b>System</b> screen.

3. Reboot the Luminoscope® to ensure that all the system components display the newly selected language.

#### Related tasks

Luminoscope® [turn off or restart](#) (pg. 134)

## 9.3 System information of the Luminoscope®

The **System information** button on the **System** screen provides access to technical data of the current setup of the Luminoscope® and can be useful for consult details about the configuration and status of the Luminoscope®.

1. Tap on the **System information** button 1 on the **System** screen.





Figure 105: **System** screen with **System information** button

The **System information** screen is now displayed.

2. Consult the information on the **System information** screen or tap on the **Abort** button.

 **Remember:** The screen may have a different appearance depending on the customer's specific implementation.




Figure 106: **System information** screen

#	Button	Description
1	<b>Abort</b> button	Return to the <b>System</b> screen.

## 9.4 Reprint last test result

The **Print last result** button on the **System** screen enables the user to reprint the last test result of the Luminoscope®.



**Remember:** The **Print last result** button only has an associated function when a ticket printer is connected to the Luminoscope®.

Tap on the **Print last result** button 1 on the **System** screen.




Figure 107: **System** screen with **Print last result** button

A duplicate of the last test result is printed on the ticket printer.

### Related information

[Test report as printed ticket](#) (pg. 97)

## 9.5 Recall recent test results

The **Recall recent results** button on the **System** screen enables the user to scroll through the recent test results of the Luminoscope® and to reprint the ticket of the selected test result.

1. Tap on the **Recall recent results** button 1 on the **System** screen.




Figure 108: **System** screen with **Recall recent results** button

The **Recent results** screen is now displayed.

2. Choose one of the options on the **Recent results** screen and tap on the corresponding button.




Figure 109: **Recent results** screen

#	Button	Description
2	<b>Select</b> button	Select one of the results to be reprinted. A duplicate of the selected test result is printed on the ticket printer.
3	<b>Details</b> button	Show or hide the measured values of the selected result.
4	<b>Abort</b> button	Return to the <b>System</b> screen.



**Tip:** Button 2 is only functional when a ticket printer is connected to the Luminoscope®.

#### Related information

[Test report as printed ticket](#) (pg. 97)

## 9.6 Import / export of data via *USB* stick

The **USB** button on the **System** screen gives access to the **USB** screen.



#### Remember:

- The **USB** button on the **System** screen appears when an *USB* stick is inserted in the connector plate of the Luminoscope®.
- Only *FAT-32*-formatted *USB* sticks are recognized. Specifically, *NTFS* format is not supported.

The **USB** screen acts as a hub for a number of functions. Among others, it gives access to the following functions which are thoroughly explained in the upcoming chapters:

- Export of a configuration file from the Luminoscope® to an *USB* stick.
- Export of test result files from the Luminoscope® to an *USB* stick.
- Export of log files from the Luminoscope® to an *USB* stick.
- Export of the configuration of vehicles (programs) and headlamps (tests) to an *USB* stick.
- Import of configuration files from an *USB* stick to the Luminoscope®.
- Import of a software update from an *USB* stick to the Luminoscope®.
- Import of a new license token configuration from an *USB* stick to the Luminoscope®.
- Import of the configuration of vehicles (programs) and headlamps (tests) from an *USB* stick to the Luminoscope®.

1. Insert a *USB* stick in the connector plate of the Luminoscope®.

**Note:** If a *USB* stick is inserted but is not accepted, the screen becomes blank with a single **Abort** button available. In such a case, remove the *USB* stick and press the **Abort** button.

2. Tap on the **USB** button 1 on the **System** screen.




Figure 110: **System** screen with **USB** button

The **USB** screen is now displayed.



**Remember:** The screen may have a different appearance depending on the customer's specific implementation.

3. Choose one of the options on the **USB** screen and tap the corresponding button.




Figure 111: **USB** screen

#	Button	Description
2	Export configuration button	Export of a configuration file from the Luminoscope® to an USB stick.
3	Export results button	Export of test result files from the Luminoscope® to an USB stick.
4	Export logs button	Export of log files from the Luminoscope® to an USB stick.

#	Button	Description
5	<b>Export vehicles and headlamps</b> button	Export of the configuration of vehicles (programs) and headlamps (tests) to an <i>USB</i> stick.
6	<b>Import configuration</b> button	Import of the configuration files from an <i>USB</i> stick to the Luminoscope®.
7	<b>Import update</b> button	Import of a software update from an <i>USB</i> stick to the Luminoscope®.
8	<b>Import license token</b> button	Import of a new licence token configuration from an <i>USB</i> stick to the Luminoscope®.
9	<b>Import vehicles and headlamps</b> button	Import of the configuration of vehicles (programs) and headlamps (tests) from an <i>USB</i> stick to the Luminoscope®.
10	<b>Abort</b> button	Return to the <b>System</b> screen.

### 9.6.1 Export operations: Luminoscope® to *USB* stick

All the following operations export different data from the Luminoscope® and write them to an *USB* stick.

#### 9.6.1.1 Export of a configuration file

The **Export configuration** button on the **USB** screen can be used to export the Luminoscope® configuration to an *USB* stick.



**Attention:** This feature is not available for the current access level. Please refer to a user who has the necessary permissions if the feature is required.

#### 9.6.1.2 Export of test result files

The **Export results** button on the **USB** screen can be used to export the Luminoscope® test result files to an *USB* stick.

After the Luminoscope® has stored the test result files on the *USB* stick, the user is offered with the option of completely deleting the exported test results from the Luminoscope® memory. This means they are no longer available for any other use in the Luminoscope®.

Starting from the **USB** screen.




Figure 112: **USB** screen with **Export results** button

1. Tap on the **Export results** button 1 on the **USB** screen.

The test result files are immediately exported to the *USB* stick. During the operation the following screen is displayed:



Figure 113: **Export results** operation progress

Once the **Export results** operation has finished, the *USB* stick can be safely removed and the following screen appears:



Figure 114: Removing test result file

After the Luminoscope® has stored the test result files on the *USB* stick, the user is offered with the option of completely deleting the exported test results from the Luminoscope® memory. This means they are no longer available for any other use in the Luminoscope®.



**Notice:** If there were no remaining test result files to export in the Luminoscope® memory, an informative screen is displayed. After pressing the **Abort** button, the screen displays the **USB** screen again.

2. Tap on the **Validation** button 3 to remove the test result files from the Luminoscope® memory or tap on the **Abort** button 2 in case the result files should be kept.

When removed, the result files will not be available anymore and the Luminoscope® displays the **USB** screen.

3. Remove the *USB* stick from the socket of the Luminoscope® connector panel and connect it to a PC.
4. Browse the *USB* stick and open its root folder.

The **Export results** operation has created a main Luminoscope® folder on the *USB* stick, if it didn't exist yet.




Figure 115: Main Luminoscope® folder on the USB stick

The syntax of the main Luminoscope® folder name follows the format LET-LM35-EPxxxxxx.xxx where the section EPxxxxxx.xxx represents the unique serial number of the optical block.

The **Export results** operation has also created a RESULTS folder under the main Luminoscope® folder, if it didn't exist yet. Each **Export results** operation creates a ZIP file in the RESULTS folder including the exported result files.




Figure 116: Folder structure on the USB stick

The naming of the exported test result file follows the format lm35-results-yyyyymmddhhmmss.zip where the section yyyyymmddhhmmss is calculated upon the file creation timestamp as explained below.

Field content	Format	Example	Explanation
Year	yyyy	2020	4-digit format.
Month	mm	03	2-digit format, left zero-padded.
Day	dd	17	2-digit format, left zero-padded.
Hour	hh	09	2-digit format, left zero-padded.
Minutes	mm	52	2-digit format, left zero-padded.
Seconds	ss	04	2-digit format, left zero-padded.
Extension	.zip	.zip	Compressed archive file extension.

The exported test result file has an internal structure which includes a pdf folder with a number of PDF test cycle report files. Each of them is the product of a single test cycle.




Figure 117: Exported test result file structure including PDF test cycle report files

The naming of each PDF test cycle report file follows the format nplate\_licenseplate\_YYYYMMDD-hhmmss.pdf including the file creation timestamp among other fields as described below.

Field content	Format	Example	Explanation
File identifier	nplate	nplate	Constant string for identification of the file contents.

Field content	Format	Example	Explanation
License plate	<i>license-plate</i>	1-BDX-236	Registration plate of the corresponding vehicle. If the number was not defined during the test, it is substituted by <i>unknown</i> .
Year	<i>yyyy</i>	2020	4-digit format.
Month	<i>mm</i>	03	2-digit format, left zero-padded.
Day	<i>dd</i>	17	2-digit format, left zero-padded.
Hour	<i>hh</i>	09	2-digit format, left zero-padded.
Minutes	<i>mm</i>	52	2-digit format, left zero-padded.
Seconds	<i>ss</i>	04	2-digit format, left zero-padded.
Extension	<i>.pdf</i>	.pdf	File extension.

5. Open the desired test cycle report file.



**Remember:** The test cycle report file may have a different appearance depending on the customer's specific implementation. Consequently, the example underneath may differ from your Luminoscope® configuration.



		Vaartlaan 20 B-9800 Deinze Tel : +32 9 381 87 87 Website : www.let.be Email : info@let.be			
Garage: OK-cars Type / Marque: LUMINOSCOPE Model / Modèle: PLA 35 Serienummer / N° série: EP200010.123 Softwareversie / Version Logiciel: xx.xx.xx LM35_XXXX					
Datum, tijd / Date, heure: 25/02/2020 10:09:23 Programma / Programme: LHD Nummerplaat / N° d'immatriculation: 1-LET-123					
Lamphoogte dimlichten / Hauteur feux de croisement: <0,8 m					
	LR / GD	ON / HB	STATUS / ETAT	I	
Voor instelling / Avant réglage:					
DIM L / FCR G:	1,40 %	-0,42 %	-	-	
DIM R / FCR D:	0,50 %	-1,09 %	-	-	
Na instelling / Après réglage:					
DIM L / FCR G:	-0,49 %	-1,20 %	OK	31,7 kCd	
DIM R / FCR D:	-0,01 %	-1,18 %	OK	30,5 kCd	
Lamphoogte grootlichten / Hauteur feux de route: <0,8 m					
	LR / GD	ON / HB	STATUS / ETAT	I	
Voor instelling / Avant réglage:					
GROOT L / FDR G:	0,59 %	1,02 %	-	-	
GROOT R / FDR D:	-1,41 %	-0,51 %	-	-	
Na instelling / Après réglage:					
GROOT L / FDR G:	0,58 %	-0,16 %	OK	42,0 kCd	
GROOT R / FDR D:	-0,04 %	-0,19 %	OK	40,9 kCd	
Lamphoogte mistlichten / Hauteur feux anti-brouillard: <0,8 m					
	LR / GD	ON / HB	STATUS / ETAT	I	
Voor instelling / Avant réglage:					
MIST L / FAB G:	-	-5,05 %	-	-	
MIST R / FAB D:	-	-1,02 %	-	-	
Na instelling / Après réglage:					
MIST L / FAB G:	-	-5,06 %	NOK	10,3 kCd	
MIST R / FAB D:	-	-2,27 %	OK	10,4 kCd	
Voertuigstatus / Résultat du véhicule: OK					
1/1					

Figure 118: Example of test cycle report

### 9.6.1.3 Export of log files

The **Export logs** button on the **USB** screen can be used to export the Luminoscope® log files to an **USB** stick.

There are two categories of files which are grouped into log files:

- Log files in text format containing a number of timestamped lines describing events, related to the activity of the Luminoscope®. The information in these log files can be useful for tracking or diagnostic tasks. It may be interesting to store or archive them for future reference. The content of these log files is not intended to be used by regular users and is continuously generated.
- Headlamp images as obtained from the camera of the Luminoscope®, so as screenshots of its user interface. They are captured simultaneously along with some diagnostic files each time the user taps on the *LET Automotive logo* on the touch screen and may be useful for future reference.

Starting from the **USB** screen.




Figure 119: **USB** screen with **Export logs** button

1. Tap on the **Export logs** button 1 on the **USB** screen.

All the different log files are immediately exported to the *USB* stick. During the operation the following screen is displayed:




Figure 120: **Export logs** operation progress

Once the **Export logs** operation has finished, the *USB* stick can be safely removed and the following screen is displayed:




Figure 121: Delete log files from the Luminoscope®

After the Luminoscope® has stored the log files on the *USB* stick, the user is offered with the option of completely deleting the exported log files from the Luminoscope®.

2. Tap on the **Validation** button 3 to remove the log files from the Luminoscope® or tap on the **Abort** button 2 in case the log files should be kept.
3. Remove the *USB* stick from the socket of the Luminoscope® connector panel and connect it to a PC.
4. Browse the *USB* stick and open its root folder.

The **Export logs** operation has created a main Luminoscope® folder on the *USB* stick if it didn't previously exist.




Figure 122: Main Luminoscope® folder on the *USB* stick

The syntax of the main Luminoscope® folder name follows the format `LET-LM35-EPxxxxxx.xxx` where the section `EPxxxxxx.xxx` represents the unique serial number of the optical block.

The **Export logs** operation has also created a `LOGS` folder under the main Luminoscope® folder, if it didn't exist yet. The **Export logs** operation creates a number of files and folders under the `LOGS` folder, depending on their availability.




Figure 123: Folder structure on the USB stick

#	Name	Explanation
4	images	This folder has been created (if it didn't exist yet) if there were camera images and screenshots of the user interface in the Luminoscope® memory.
5	08	This subfolder has been created (if it didn't exist yet), labeled with the (zero-padded) current day of the month of the <b>Export logs</b> operation. Successive applications of the <b>Export logs</b> operation may create similar folders.
6	camera	This subfolder has been created (if it didn't exist yet), if there were any pictures to be exported. It contains a variable number of <i>PNG</i> files, each of them generated by the tapping on the <i>LET Automotive logo</i> of the Luminoscope® screen and containing a screenshot of the status of the device camera. Successive applications of the <b>Export logs</b> operation may add more pictures to this folder. The name of the picture includes the file creation timestamp.
7	screenshots	This subfolder has been created (if it didn't exist yet), if there were any pictures to be exported. It contains a variable number of <i>PNG</i> files, each of them generated by the tapping on the <i>LET Automotive logo</i> of the Luminoscope® screen and containing a screenshot of the status of the user interface of the device. Successive applications of the <b>Export logs</b> operation may add more pictures to this folder. The name of the picture includes the file creation timestamp.
8	Sys	This subfolder has been created (if it didn't exist yet), if there were diagnostic files to be exported. It contains useful diagnosing information and it is not intended for regular users but may be eventually requested by LET service technicians. Successive applications of the <b>Export logs</b> operation update the content of this folder.

#	Name	Explanation
9	log files	Text files containing a number of timestamped lines describing events related to the activity of the Luminoscope®. Each file is named with a timestamp and contains the events happening on that date. Successive applications of the <b>Export logs</b> operation may then either append to existing files or add new files to the list.

#### 9.6.1.4 Export of a configuration file of vehicles and headlamps

The **Export vehicles and headlamps** button on the **USB** screen can be used to export a specific part of the Luminoscope® configuration to an *USB* stick. This operation specifically exports the vehicles (*programs*) and headlamps (*tests*) with all their related parameters from the database, while excluding any other configuration parameter.



**Attention:** This feature is not available for the current access level. Please refer to a user who has the necessary permissions if the feature is required.

### 9.6.2 Import operations: *USB* to Luminoscope®

All the following operations read different data from an *USB* stick and write them to the Luminoscope®.

#### 9.6.2.1 Import of a configuration file

The **Import configuration** button on the **USB** screen can be used to import a configuration file (that was previously stored on an *USB* stick) to the Luminoscope®. The **Import configuration** operation allows restoring the Luminoscope® to a previous status for which an **Export configuration** operation was done.



**Attention:** This feature is not available for the current access level. Please refer to a user who has the necessary permissions if the feature is required.

#### 9.6.2.2 Software update from a *USB* stick

The **Import update** button on the **USB** screen can be used to update the system software from a properly crafted *USB* stick. This functionality allows the user to apply, under remote supervision by LET technicians, specific small patches for particular parts of the system in order to modify its behavior or configuration details.



**Attention:** This feature is not available for the current access level. Please refer to a user who has the necessary permissions if the feature is required.

#### 9.6.2.3 Import of a *license token file*

The **Import license token** button on the **USB** screen can be used to import a new *license token file* from an *USB* stick to the *USB License Dongle* in the Luminoscope®.



**Attention:** This feature is not available for the current access level. Please refer to a user who has the necessary permissions if the feature is required.

#### 9.6.2.4 Import of a configuration file of vehicles and headlamps

The **Import vehicles and headlamps** button on the **USB** screen can be used to import a specific part of the Luminoscope® configuration that was previously stored on an *USB* stick to the Luminoscope® memory. This operation specifically imports the vehicles (*programs*) and headlamps (*tests*) with all their related parameters from the database, while excluding any other configuration parameter.



**Attention:** This feature is not available for the current access level. Please refer to a user who has the necessary permissions if the feature is required.



# 10 Setup screen

The **Setup** screen acts as a hub for a number of functions. Among others, it gives access to the following functions which are thoroughly explained in the upcoming chapters:

- Turn off or restart the Luminoscope®.
- Computer configuration of the Luminoscope®.
- Settings program menu.
- Verification menu.
- Calibration menu.

When powered up, the Luminoscope® displays the **Program selection** screen. Follow the navigation sequence below for reaching the **Setup** screen.

1. Tap on the **System** button 1 on the **Program selection** screen.



**Remember:** The screen may have a different appearance depending on the customer's specific implementation.



Figure 124: **Program selection** screen with **System** button

The **System** screen is now displayed.

2. Tap on the **Setup** button 2 on the **System** screen.




Figure 125: **System** screen with **Setup** button

The **Setup login** screen is now displayed.

3. Enter your credentials 3 and tap on the **Validation** button 4. Alternatively tap on the **Abort** button 5 to return to the **System** screen.




Figure 126: **Setup login** screen

The access to the different menus and their options is hierarchical and depends on the access rights of each login, which is identified with a password as follows:

Level	Login	Password	Description
Operator	1	1234	Operator staff working with the equipment.
Maintenance	2	Confidential	Maintenance staff and production leaders have access to most common functions except data related with vehicles and headlamps.
Process	3	Confidential	Process staff have additional access to data related to vehicles and headlamps.

Level	Login	Password	Description
Integrator	4	Confidential	<i>Third-party company</i> responsible for the integration of the Luminoscope® in a production or audit line.
<i>LET Service Engineer</i>	5	Confidential	LET Service Engineer.

**Important:** These passwords are hard-coded and cannot be changed.

The following screen appears when either wrong or no credentials at all are introduced. In this case the **Setup** screen will be automatically displayed with very limited access rights.




Figure 127: **Login not OK** screen

4. Choose one of the options on the **Setup** screen and tap on the corresponding button.




Figure 128: **Setup** screen



**Remember:** The **Setup** screen, **Computer configuration** screen, **Settings program** screen, **Verification** screen and **Calibration** screen may have different appearances depending on the customer's specific implementation and the applied login level.

Consequently, probably not all functions listed in the table below are accessible.

#	Button	Description
6	<b>Power</b> button	Turn off or restart the Luminoscope®.
7	<b>Computer configuration</b> button	<p>Amongst others, the <b>Computer configuration</b> screen gives access to the following functions:</p> <ul style="list-style-type: none"> <li>• Date and time setup</li> <li>• <i>Wi-Fi</i> setup</li> <li>• <i>Ethernet</i> setup</li> <li>• <i>Bluetooth</i> setup</li> <li>• <i>HDMI</i> monitor setup</li> <li>• Check for and apply available firmware updates</li> <li>• Log file information</li> <li>• Licensing information</li> </ul>
8	<b>Settings program</b> button	<p>The settings program (system database) provides access to the following items:</p> <ul style="list-style-type: none"> <li>• Vehicle parameters (programs)</li> <li>• Headlamp parameters (tests)</li> <li>• Component parameters</li> <li>• User parameters</li> </ul>
9	<b>Verification</b> button	<p>Among others, the <b>Verification</b> screen gives access to the following functions:</p> <ul style="list-style-type: none"> <li>• <i>Zero reference</i> verification</li> <li>• <i>Intensity</i> verification</li> <li>• <i>I/O</i> diagnostics: parallel, serial and Bluetooth</li> <li>• <i>System information</i></li> <li>• <i>Position Check</i> verification</li> <li>• <i>ESL</i> (Electronic Spirit Level) module verification</li> <li>• <i>Light modulation</i> verification</li> <li>• <i>Electronic height measurement</i> verification</li> <li>• Battery verification</li> <li>• <i>CAN bus</i> modules verification</li> </ul>
10	<b>Calibration</b> button	<p>Among others, the <b>Calibration</b> screen gives access to the following functions:</p> <ul style="list-style-type: none"> <li>• Direct camera connection</li> <li>• <i>Zero reference</i> calibration</li> <li>• <i>Position Check</i> calibration</li> <li>• <i>ESL</i> (Electronic Spirit Level) module calibration</li> <li>• <i>Electronic height measurement</i> calibration</li> <li>• Battery calibration</li> </ul>
11	<b>Abort</b> button	Return to the <b>Program selection</b> screen.

**Related tasks**

[Computer configuration screen](#) (pg. 161)

**Related information**

[Power management](#) (pg. 55)



---

# 11 Computer configuration screen

---

The **Computer configuration** screen acts as a hub for a number of functions. Among others, it gives access to the following functions, which are thoroughly described in the upcoming chapters:

- Date and time setup.
- *Wi-Fi* setup.
- *Ethernet* setup.
- *Bluetooth* setup.
- External *HDMI* monitor setup.
- Check for and apply available firmware updates.
- Log file information.
- Delete log and result files.
- Licensing information.

The **Computer configuration** screen is reached via a button on the **Setup** screen. If needed, please check relevant link at the end of this chapter.

Starting from the **Setup** screen.

1. Tap on the **Computer configuration** button 1 of the **Setup** screen.




Figure 129: **Setup** screen with **Computer configuration** button

The **Computer configuration** screen is now displayed.

2. Choose one of the options of the **Computer configuration** screen and tap on the corresponding button.





Figure 130: **Computer configuration** screen

 **Remember:** The screen may have a different appearance depending on the customer's specific implementation and the applied access level.

#	Button	Description
2	<b>Wi-Fi</b> button	Wi-Fi connection setup.
3	<b>Ethernet</b> button	Ethernet connection setup.
4	<b>Bluetooth</b> button <sup>1</sup>	Bluetooth connection setup.
5	<b>External HDMI monitor</b> button <sup>1</sup>	External <i>HDMI</i> monitor setup.
6	<b>Delete logs and results</b> button <sup>1</sup>	Delete log and result files from the Luminoscope®.
7	<b>Date and time</b> button	Date and time setup.
8	<b>Online firmware update</b> button <sup>1</sup>	Check for and apply available firmware updates.
9	<b>View log</b> button <sup>1</sup>	Check log files.
10	<b>Licensing information</b> button <sup>1</sup>	Check software licensing info.
11	<b>Abort</b> button	Return to the <b>Setup</b> screen.

<sup>1</sup> Function not available for the current access level.

**Related tasks**

[Setup screen](#) (pg. 155)

**11.1 Date and time setup**

The **Date and time** button on the **Computer configuration** screen gives access to the menu to configure the date and time settings of the Luminoscope®.

Date and time settings can be achieved either manually or via an automatic synchronization over the network.

Starting from the **Computer configuration** screen.




Figure 131: **Computer configuration** screen with **Date and time** button

1. Tap on the **Date and time** button 1 on the **Computer configuration** screen.

The **Time zone settings** screen is now displayed.




Figure 132: Time zone settings

2. Select the correct time zone region 2 and the nearest city 3 out from the list.
3. Tap on the **Save** button 4 to save the settings. Alternatively tap on the **Abort** button 5 to return to the **Computer configuration** screen.

### 11.1.1 Manual date and time setting

The Luminoscope® date and time can be set manually.

Start from the **Date and time setup** screen.




Figure 133: Manual date and time setup

1. Select **Manual** option from the **Configuration** menu 1.

2. Set the correct day 2, month 3 and year 4.
3. Set hour, minutes and seconds by using the corresponding up 5 and down 6 arrows.
4. Tap on the **Save** button 7 to save the settings. Alternatively tap on the **Abort** button 8 to return to the **Computer configuration** screen.

### 11.1.2 Automatic date and time setup

The Luminoscope® date and time can be set to automatically synchronize over the network.



**Remember:** The Luminoscope® must be connected to a network providing access to the *NTP* server which is to be used. Additionally it also needs connectivity for a *DNS* server. Make sure the following ports of the selected servers are reachable:

- *NTP* server, port *UDP/123*.
- *DNS* server, port *UDP/53* and port *TCP/53*.

Start from the **Date and time setup** screen.




Figure 134: Automatic date and time setup

1. Select **Automatic time sync** from the **Configuration** menu 1.

**Note:** The **Date and time settings** controls can no longer be changed manually.

2. Enter the name or address of the time server 2 (e.g. *pool.ntp.org*).
3. Tap on the **Save** button 3 to save the settings. Alternatively tap on the **Abort** button 4 to return to the **Computer configuration** screen.

## 11.2 Wi-Fi networking

The **Wi-Fi** button on the **Computer configuration** screen gives access to the configuration of the different *Wi-Fi* network operations and settings of the Luminoscope®.

The Luminoscope® *Wi-Fi* networking can operate in two different modes:

- **AP mode**, on which the Luminoscope® acts as a *Wi-Fi* local access point (AP). This mode doesn't provide any additional routing to other networks and is limited to the access to the Luminoscope® provided services. It is very convenient when there is no available *Wi-Fi* infrastructure on the site.
- **Regular mode**, connecting the Luminoscope® to an available *Wi-Fi* network via either *Dynamic Host Configuration Protocol (DHCP)* or specifying a static connection networking set of parameters.

Start from the **Computer configuration** screen.




Figure 135: **Computer configuration** screen with **Wi-Fi** button

Tap on the **Wi-Fi** button 1 on the **Computer configuration** screen.

The **Wi-Fi settings** screen is now displayed and the **General info** tab is active.




Figure 136: **Wi-Fi settings** screen with **general info**



**Tip:** The screen may have a different appearance depending on the earlier applied *Wi-Fi* settings.

#	Name	Description
2	<b>Wi-Fi ON / OFF</b> switch	Enables or disables <i>Wi-Fi</i> communication.
3	<b>Connection status</b> indication	Shows if the wireless connection is currently stablished and usable.
4	<b>AP mode</b> switch	Controls the <i>Wi-Fi</i> networking working mode of the Luminoscope®, switching between <i>AP mode</i> and <i>Regular mode</i> .
5	<b>Wi-Fi autoconnect</b> switch	Enables or disables automatic connection to the last <i>Wi-Fi</i> network.
6	<b>General info</b> tab	Provides access to the General information on the <i>Wi-Fi</i> communication: <ul style="list-style-type: none"> <li>• MAC address of the physical interface</li> <li>• IP address of the Luminoscope®</li> <li>• Network Mask</li> <li>• RX bytes (number of received bytes)</li> <li>• TX bytes (number of transmitted bytes)</li> <li>• SSID (Service Set Identifier)</li> <li>• Signal strength</li> </ul>
7	<b>Networking setup</b> tab	Provides access to the Network setup for the <i>Wi-Fi</i> configuration. <ul style="list-style-type: none"> <li>• DHCP (Dynamic Host Configuration Protocol) ON/OFF switch.</li> </ul> In case DHCP is not selected: <ul style="list-style-type: none"> <li>• IP address</li> <li>• Netmask</li> <li>• Gateway</li> <li>• DNS server</li> </ul>
8	<b>Network list</b> tab	Provides access to a list of available <i>Wi-Fi</i> networks including the signal strength and the <i>Wi-Fi</i> protection type. It allows the operator to select the network to connect to.
9	<b>Save setup</b> button	Saves the current setup for being used upon a restart.
10	<b>Abort</b> button	Returns to the <b>Computer configuration</b> screen.

### 11.2.1 *Wi-Fi* applications

The applications of the *Wi-Fi* connection are among others:

- Remotely operating the Luminoscope®. This is achieved via the VNC-protocol access to the Luminoscope®. Both **AP mode** and **Regular mode** provide support for this application.
- Remotely accessing the configuration of the Luminoscope®, providing the eventual maintenance or technical staff with the possibility of completing their task from a suitable or adequate workplace. This is achieved via the VNC-protocol access to the Luminoscope®. Both **AP mode** and **Regular mode** provide support for this application.

However, operations such *Remote Upload* or *Check for Updates* over network, for which the Luminoscope® needs internet access, cannot be completed unless the **Regular mode** is active.

- Integration of the Luminoscope® into an upper level network for sharing the inspection reports outcome data with a higher level system as technical registers, factories' SCADAs (*Supervisory Control and Data Acquisition*), databases and so on. The nature of these networking applications is better achieved with the **Regular mode** which purpose is more focused on a permanent connection.
- Remotely accessing the Web Interface of the Luminoscope®.

In all cases, any multimedia device (desktop, laptop, tablet, smartphone, etc.) can be used as the client for these activities.

Requirements are:

- Proper *Wi-Fi* connectivity
- VNC protocol client available

The upcoming chapters explain how the Luminoscope® can be switched between the described modes and how to manage the connection of the Luminoscope® to an available *Wi-Fi* network.

#### Related information

[Remote operation](#) (pg. 179)

### 11.2.2 Local Access Point setup

The Luminoscope® can be configured to act as a *Wi-Fi* local access point (*AP mode* for short).

Starting from the **Wi-Fi settings** screen.

1. Enable the *AP mode* by setting the **AP mode** switch 4 to its **ON** position.  
The Luminoscope® creates a *Wi-Fi* hotspot with the name `LuminoscopeAP`.
2. Tap on the **Save setup** button 9 to save the current settings and use them upon restart.
3. Connect a *Wi-Fi* equipped laptop to the hotspot `LuminoscopeAP`.  
Use the password `Luminoscope00` (with two trailing zeros) for that purpose.
4. Check the relevant link at the end of this chapter for a clear explanation on how to remotely control the Luminoscope® via a VNC client installed on a laptop.
5. Configure the Luminoscope® as required.  
Remotely complete the configuration of the different settings with the convenience and flexibility of the *Wi-Fi* network range.
6. Once finished, disable the *AP mode* by setting the **AP mode** switch 4 to its **OFF** position.
7. Tap on the **Save setup** button 9 to save the current settings and use them upon restart.

**Related information**

[Remote operation](#) (pg. 179)

**11.2.3 Regular mode setup**

The Luminoscope® can be connected to an available *Wi-Fi* network via either *Dynamic Host Configuration Protocol (DHCP)* or specifying a static connection networking parameter set.

Starting from the **Wi-Fi settings** screen.

**Enable/disable the *Wi-Fi* communications:**

1. Set the *Wi-Fi* **ON / OFF** switch 2 to the **ON** position to enable the *Wi-Fi* communications. Alternatively, set the switch to **OFF** to disable them.
2. Tap on the **Network list** tab 8.  
The **Wi-Fi networks List** screen is now displayed.



Figure 137: **Wi-Fi networks List** screen without available networks

3. Tap on the **Refresh** button 11 to show all available *Wi-Fi* SSIDs (wireless network names) or to refresh the network list.  
The following screen is displayed:




Figure 138: **Wi-Fi networks List** screen with available Wi-Fi networks



**Tip:** The network list may have a different appearance and content depending on the available *Wi-Fi* networks and the customer's specific implementation.

A yellow star icon 13 signals the *Wi-Fi* network *SSID* to which the Luminoscope® is connected if so. Otherwise, there is no star icon associated to any network.

4. Activate the **Wi-Fi autoconnect** switch 5 in order to automatically connect to the last *Wi-Fi* network.

**If it is needed to connect to another *SSID*:**

5. Delete the current *Wi-Fi* connection setup initially by tapping on the **Disconnect** button 12 if already established.
6. Select the preferred *SSID* by tapping on it.  
The selected network is highlighted.

**Note:**

- Use the *SSID* with the strongest signal for which you have proper credentials.
- A stable and dependable *Wi-Fi* link will require a signal level stronger than -75dBm.
- WPA2 protection is mandatory.

7. Tap on the **Connect** button 10 to connect to the selected *SSID*.  
The following screen is displayed:




Figure 139: **Wi-Fi networks List** screen with password entry

8. Enter the *Wi-Fi* network password and tap on the **Connect** button 14 on the pop-up screen.
9. Tap on the **Save setup** button 9 to save the current settings and use them upon restart.
10. Tap on the **Refresh** button 11 to update the network list.



**Tip:** The chosen network *SSID* is marked with a yellow star icon.

#### Recalling the data corresponding with the current connection:

11. Tap on the **General info** tab 6 to consult the info about the *Wi-Fi* communication.
  - **MAC address**
  - **IP address**
  - **Netmask**
  - **RX bytes** (Received bytes)
  - **TX bytes** (Transmitted bytes)
  - **SSID** (Service Set Identifier i.e. wireless network name)
  - **Signal Strength**

The following screen is displayed:




Figure 140: **Wi-Fi networks List** screen with *General info*

**Accessing for modifying or querying the network details of the Wi-Fi connection:**

12. Tap on the **Networking setup** tab 7 to modify the *Wi-Fi* info.

The following screen is displayed:




Figure 141: **Wi-Fi networks List** screen with network configuration

The networking parameters can be set manually or automatically via *DHCP*.

**Obtaining network parameters automatically via DHCP:**

13. Set the **DHCP** switch 15 to **ON** to let the Luminoscope® adjust the network parameters without manual intervention.  
The Luminoscope® dialogs with the *DHCP* server to obtain the applicable set of networking parameters and they are updated on the display fields.
14. Tap on the **Apply** button 16 to apply the new values to the current connection.

15. Tap on the **Save setup** button 9 to save the current settings and use them upon restart.

**Setting the network parameters manually:**

16. Set the **DHCP** switch 15 to **OFF** to manually enter the networking parameters.  
Depending on the specific network setup, it may be interesting to set manually the network parameters.
17. Set the correct network values.  
Carefully enter the proper valid values for:
- **IP address**
  - **Netmask**
  - **Gateway**
  - **DNS**
18. Tap on the **Apply** button 16 to apply the new values to the current connection.
19. Tap on the **Save setup** button 9 to save the current settings and use them upon restart.

### 11.3 Ethernet networking

The **Ethernet** button on the **Computer configuration** screen gives access to the configuration of the *Ethernet* network operations and settings of the Luminoscope®.



**Remember:** Some Luminoscope® optical blocks are provided with the optional *Ethernet* port on their connector plate. The settings underneath may not be of application for your specific Luminoscope®.

Starting from the **Computer configuration** screen.




Figure 142: **Computer configuration** screen with **Ethernet** button

Tap on the **Ethernet** button 1 on the **Computer configuration** screen.  
The **Ethernet settings** screen is now displayed and the **General info** tab is active.





Figure 143: **Ethernet settings** screen with general info

 **Tip:** The screen may have a different appearance depending on the earlier applied *Ethernet* settings.

#	Name	Description
2	<b>Ethernet ON / OFF</b> switch	Enables or disables the <i>Ethernet</i> communication.
3	<b>Connection</b> status indicator	Shows if the <i>Ethernet</i> wired connection is currently established and usable.

#	Name	Description
4	<b>General info</b> tab	Provides access to the General information on the <i>Ethernet</i> communication configuration: <ul style="list-style-type: none"> <li>• MAC address of the physical interface</li> <li>• IP address of the Luminoscope®</li> <li>• Network Mask</li> <li>• RX bytes (number of received bytes)</li> <li>• TX bytes (number of transmitted bytes)</li> </ul>
5	<b>Networking setup</b> tab	Provides access to the Network setup for the <i>Ethernet</i> configuration. <ul style="list-style-type: none"> <li>• DHCP (Dynamic Host Configuration Protocol) ON/OFF switch.</li> </ul> In case DHCP is not selected: <ul style="list-style-type: none"> <li>• IP address</li> <li>• Netmask</li> <li>• Gateway</li> <li>• DNS server</li> </ul>
6	<b>Save setup</b> button	Saves the current setup for being used upon restart.
7	<b>Abort</b> button	Returns to the <b>Computer configuration</b> screen.

### 11.3.1 *Ethernet* applications

The applications of the *Ethernet* connection are among others:

- Remotely operating the Luminoscope®. This is achieved via the VNC-protocol access to the Luminoscope®.
- Integration of the Luminoscope® into an upper level network for sharing the inspection reports outcome data with a higher level system as technical registers, factories' SCADAs (*Supervisory Control and Data Acquisition*), databases and so on.
- Remotely accessing the Web Interface of the Luminoscope®.

In all cases, a desktop or a laptop computer can be used as the client for these activities.

Requirements are:

- Proper *Ethernet* connectivity
- VNC protocol client available

The upcoming chapter explains how to manage the connection of the Luminoscope® to an available *Ethernet* network.

#### Related information

[Remote operation](#) (pg. 179)

### 11.3.2 *Ethernet* setup

The Luminoscope® can be connected to an available *Ethernet* network via either *Dynamic Host Configuration Protocol (DHCP)* or specifying a static connection networking parameter set.

Starting from the **Ethernet settings** screen.

#### Enable/disable the *Ethernet* communications:

1. Set the *Ethernet* **ON / OFF** switch 2 to the **ON** position to enable the *Ethernet* communications. Alternatively set the switch to **OFF** to disable them.  
The **Connection** status indicator 3 reflects the changes on the network connection availability.

#### Recalling the data corresponding with the current connection:

2. Tap on the **General info** tab 4.  
The following screen is displayed:




Figure 144: **Ethernet settings** screen with **General info** tab

The currently applied network parameters can be reviewed:

- **MAC address** of the physical interface
- **IP address** of the Luminoscope®
- **Network mask**
- **RX bytes** (Received bytes)
- **TX bytes** (Transmitted bytes)

#### Obtaining network parameters automatically via *DHCP*:

3. Tap on the **Networking setup** tab 5.  
The following screen is displayed:




Figure 145: **Ethernet settings** screen with **Networking setup** tab activated changing **DHCP** status

4. Set the **DHCP** switch 8 to **ON** to let the Luminoscope® adjust the network parameters without manual intervention.

The Luminoscope® dialogs with the **DHCP** server to obtain the applicable set of network parameters so it can communicate efficiently with other network connected devices. **DHCP** also assigns the subnet mask, default gateway address, domain name server (**DNS**) address and other pertinent configuration parameters.

Of course, the network to which the Luminoscope® is connected must count with an appropriately configured **DHCP** server.

Once the IP address is assigned, the rest of inputs (IP address, Netmask, Gateway and **DNS**) are updated with the obtained values and disabled.

5. Tap on the **Apply** button 9 to apply the new values to the current connection.  
Once the values are correct and the network connection is established, the **Connection** status indicator 3 is updated.
6. Tap on the **Save setup** button 6 to save the current settings and use them upon restart.

#### Setting the network parameters manually:

7. Set the **DHCP** switch 8 to **OFF** to manually enter the network parameters.

The Luminoscope® requires a set of network parameters so it can communicate efficiently with other network connected devices.

8. Set the correct network values.  
Carefully enter the proper valid values for:

- **IP address**
- **Netmask**
- **Gateway**
- **DNS**

9. Tap on the **Apply** button 9 to apply the new values to the current connection.

Once the values are correct and the network connection is established, the **Connection** status indicator 3 is updated.

10. Tap on the **Save setup** button 6 to save the current settings and use them upon restart.

---

# 12 Remote operation

---

This chapter explains how to connect a remote device (tablet, smartphone, laptop, desktop, ...) to the Luminoscope® over *Wi-Fi* in order to remotely control the Luminoscope®.

The instructions below require a *VNC* client to be installed on the remote device, and that both the Luminoscope® and the remote device are properly connected to the corresponding *Wi-Fi* access points of the network, allowing mutual IP access.

**Note:**

- The following instructions can be applied to any platform which has a *VNC* client installed.
- The present explanation refers to an *Android* tablet using the freely available *bVNC* application. Neither of the *VNC* client or the remote device are exclusively supported by the Luminoscope®.



**Remember:** The screen displayed on the tablet may have a different appearance depending on customer's specific implementation.



Figure 146: Luminoscope® screen displayed on a tablet

## 12.1 VNC client setup



**Remember:** The following instructions refer to the *bVNC* application and will be similar but not identical for any other client. Take also into account that the *bVNC* application appearance may differ to the one depicted below.

1. Locate the *IP* address 1 of the Luminoscope® on the **System information** screen that is accesible via the **System** screen.




Figure 147: **System information** screen displaying the Wi-Fi IP address

**2. Write down the IP address.**

It will be used in an upcoming step.

**3. Open the *bVNC* application 2 on the tablet.**



Figure 148: *bVNC* icon on tablet screen

Eventually, the next message or a similar one is displayed.




Figure 149: bVNC application message

4. Tap on the **Close** button 3.

The following screen is displayed.




Figure 150: Connection name in the bVNC application

5. Enter a name for identifying the connection 4 (e.g. **Im35**).

6. Tap on the **Next** button 5.

The following screen is displayed.




Figure 151: Luminoscope® IP address in the bVNC application

7. Enter the IP address of the Wi-Fi connection of the Luminoscope® 6 (e.g. **172.16.21.9**).
8. Enter the hardcoded password 7 to complete the configuration.  
Use **Luminoscope** as the VNC password.



**Tip:** No VNC username is required.




Figure 152: VNC connection password in bVNC application

9. Tap on the **Connect** button 8.

A copy of the Luminoscope® screen appears on the tablet screen and the system can now be remotely controlled.

### Related tasks

[System information of the Luminoscope \(pg. 137\)](#)

## 12.2 Terminate the session

Once the interaction with the Luminoscope® is no longer needed, it is advisable to properly terminate the session.



**Remember:** The following instructions are specific for the *bVNC* application on an *Android* tablet, but the same functionality is available for any other platform and VNC client.

Starting from the connected *bVNC* application.



Figure 153: Invoke the *bVNC* application auxiliary buttons

1. Tap anywhere out from the Luminoscope® screen image 1 on the tablet to invoke the overlay auxiliary buttons of the *bVNC* application.

The following screen is displayed.



Figure 154: **Dotted icon** button

2. Tap on the **dotted icon** button 2 to invoke the pop-up configuration menu of the *bVNC* application.

The following screen is displayed.




Figure 155: *bVNC* pop-up configuration menu

**Note:** The shape and layout of the pop-up configuration menu may differ from yours.

3. Tap on the **Disconnect** button 3 of the pop-up of the *bVNC* application.  
The link between both device's displays is now terminated.

# 13 Web interface

This chapter explains how to operate the *web interface* of the Luminoscope® on a remote device (tablet, smartphone, laptop, desktop, ...). The remote device should have a *web browser* (e.g. Google Chrome, Firefox, ...) for accessing the *web interface*.

The *web interface* has many functions. Among others, it gives access to the following functions which are thoroughly explained in the upcoming chapters:

- Check the contact information of LET Automotive.
- Upload a logo on the *PDF* test reports.
- Check and/or print the *PDF* test reports.
- Export the configuration file (backup file) of the Luminoscope®.
- Check or modify some settings in the Luminoscope®.
- Check the log files of the Luminoscope®.
- Check the stored camera images of the Luminoscope®.
- Check the stored screenshots of the Luminoscope®.
- Remotely operate the Luminoscope®.

**Note:** Both the Luminoscope® and the remote device should be properly connected to the same network (*LAN* or *Wi-Fi*), allowing mutual IP access. At the end of the chapter there is a link with related information on how to connect the Luminoscope® to a *Wi-Fi* network or *Ethernet* network.



**Remember:** Some Luminoscope® optical blocks are provided with an optional *Ethernet* port on the connector plate. Consequently the *web interface* should be accessed over *Wi-Fi* if the Luminoscope® has no *Ethernet* port.

The access to the options in the *web interface* is hierarchical and depends on the access rights of each login, which is identified with a password as follows:

Level	Login	Password	Description
Operator	1	1234	<i>Operator staff</i> working with the equipment.
Maintenance	2	Confidential	<i>Maintenance staff</i> and <i>production leaders</i> have access to most common functions except data related with vehicles and headlamps.
Process	3	Confidential	<i>Process staff</i> have additional access to data related to vehicles and headlamps.
Integrator	4	Confidential	<i>Third-party company</i> responsible for the integration of the Luminoscope® in a production or audit line.
LET Service Engineer	5	Confidential	LET Service Engineer.

## 13.1 Access to the *web interface*

The following instructions explain how to access the *web interface* of the Luminoscope® either via the *LAN IP* address; *Wi-Fi IP* address or *host name* of the Luminoscope®. The *web interface* will appear in the *web browser* of a remote device.

1. Open the **System information** screen that is accessible via the **System** screen.




Figure 156: **System information** screen with system details for web connection

2. Locate the *LAN IP address* 1 (if applicable), the *Wi-Fi IP address* 2 or the *host name* 3.
3. Enter the corresponding address in any of these forms, in the navigation bar of a web browser of a remote device, prepended with the protocol scheme (`http://`).




Figure 157: Browser navigation bar pointing to the LAN IP address, the Wi-Fi IP address and the hostname of the Luminoscope®, from top to bottom

4. Tap on the **Enter** button on the remote device.  
The **Web interface main** screen is now displayed:




Figure 158: **Web interface main** screen



**Tip:** It's recommended to create a shortcut in the web browser, for easily connecting to the Luminoscope® *web interface*.

5. Enter the login name 4 and password 5 in order to enable more functions of the *web interface*.

Use the table above to select the proper login and password for the corresponding access level.

The following screen is now displayed:




Figure 159: **Web interface main screen**

The following information fields, selection fields and buttons are available.

#	Element	Description
6	<b>Logout button</b>	Logout from the <i>web interface</i> .
7	<b>Information field</b>	<i>LET Automotive</i> contact information.
8	<b>Information link</b>	Displays <i>LET Automotive</i> contact information.
9	<b>Upload logo link</b>	Upload a logo (in <i>PNG</i> format) for the <i>PDF</i> test reports.
10	<b>Results link</b>	Check and/or print the <i>PDF</i> test reports.
11	<b>Backup link</b>	Export the configuration file (backup file) from the Luminoscope® to a remote device.
12	<b>Settings link</b>	Check and/or modify some settings of the Luminoscope®: Customer settings: Name, Address, Phone, E-mail.
13	<b>Advanced link</b>	Access the advanced settings of the Luminoscope®: <ul style="list-style-type: none"> <li>• Check the log files.</li> <li>• Check the stored camera images.</li> <li>• Check the stored screenshots.</li> <li>• Remote operation.</li> </ul>

The following chapters explain the different functionalities of the *web interface*.

After logging in with the applicable password, the user has access to more functions of the *web interface*. From now on the session is called an *authorized session*.

#### Related tasks

[Wi-Fi networking](#) (pg. 166)

[Ethernet networking](#) (pg. 173)

## 13.2 Upload a customer logo for the *PDF* test reports

This chapter explains how to upload a logo (in *PNG* format) to be displayed, centered on top of the *PDF* test reports in the *web interface*.

Starting from the **Web interface main** screen in an authorized session.



**Tip:** This functionality can also be achieved by a user which has not been logged in.




Figure 160: **Web interface main** screen in an authorized session

1. Click on the **Upload logo** link 1 on the **Web interface main** screen.

The following screen is now displayed:




Figure 161: **Upload logo** screen

2. Browse to a customer logo (PNG format) and store the image to the Luminoscope®. The customer logo will now be shown centered on top of each PDF test report.

### 13.3 Check and/or print the PDF test reports

This chapter explains how to check and/or print the PDF test reports in the *web interface*.

Starting from the **Web interface main** screen in an authorized session.




Figure 162: **Web interface main** screen in an authorized session

1. Click on the **Results** link 1 on the **Web interface main** screen. The following screen is now displayed:




Figure 163: **Results** screen

The screen shows a list of all available test results. The test results can be split into different tab pages. Each entry shows the date and time, number plate (if applicable), VIN (vehicle identification number - if applicable) and the global result (passed or failed) of a test result.

2. Click on the **Print results** link 3 of a test result.

The *PDF* test report is now displayed in an extra tab page in the web browser. The *PDF* test report can be downloaded and then stored locally or printed on a local printer.

3. Tap on the **Reload results** button 2 for checking the availability of more test results. All available test results are now displayed.

## 13.4 Export the configuration file of the Luminoscope®

This chapter explains how to export a configuration file (backup file) from the Luminoscope® to a remote device via the *web interface*.

Starting from the **Web interface main** screen in an authorized session.




Figure 164: **Web interface main** screen in an authorized session

1. Click on the **Backup** link 1 on the **Web interface main** screen.

The following screen is now displayed:




Figure 165: **Backup** screen

2. Tap on the **Download configuration backup** button 2 and choose a location for storing the configuration file of the Luminoscope® to the remote device.

The configuration file of the Luminoscope® has now been exported from the Luminoscope® and stored at the chosen location.

## 13.5 Check and/or modify some settings of the Luminoscope®

This chapter explains how to check and/or modify some settings of the Luminoscope®.

Starting from the **Web interface main** screen in an authorized session.




Figure 166: **Web interface main** screen in an authorized session

1. Click on the **Settings** link 1 on the **Web interface main** screen.

The following screen is now displayed:




Figure 167: **Settings** screen

### Modify customer settings

2. Click on the **Customer** link 2 to access the **Customer settings** screen.

The following screen is now displayed:




Figure 168: **Customer settings** screen

3. Tap on the corresponding **Load** button to retrieve the current setting.
4. Check and/or modify the required information: customer name, customer address, customer phone number, customer e-mail address.
5. Tap on the corresponding **Save** button to store the setting to the Luminoscope®. The modified settings will now be shown on top of each *PDF* test report.

## 13.6 Check stored info and remotely operate the Luminoscope®

This chapter explains how to access some stored info in the Luminoscope® such as log files, camera images and screenshots and how to remotely operate the Luminoscope®.

Starting from the **Web interface main** screen in an authorized session.




Figure 169: **Web interface main** screen in an authorized session

Click on the **Advanced** link 1 on the **Web interface main** screen.  
The following screen is now displayed:




Figure 170: **Advanced** screen

The following options are available:

#	Element	Description
2	<b>Logs</b> link	Displays a list of all available log files in the Luminoscope®.
3	<b>Camera images</b> link	Displays a list of all available camera images in the Luminoscope®.
4	<b>Screenshots</b> link	Displays a list of all available screenshots in the Luminoscope®.
5	<b>Remote</b> link	Access to the remote operation of the Luminoscope®.

### 13.6.1 Access to log files

Log files in text format contain a number of timestamped lines describing events, related to the activity of the Luminoscope®. The information in these log files can be useful for tracking or diagnostic tasks. It may be interesting to store or archive them for future reference. The content of these log files is not intended to be used by regular users and is continuously generated.

Starting from the **Advanced** screen.

1. Click on the **Logs** link 2 on the **Advanced** screen to access the **Logs** screen.

The following screen is now displayed.




Figure 171: **Logs** screen

2. Tap on the **Load files list** button 6.

The following screen is displayed:




Figure 172: **Logs** screen with all available log files

The screen shows a list of all available log files. Each entry shows the date and time and the file size.

3. Click on the **Download** link 7 to download the log file. Alternatively tap on the log file name to open the log file.

The log file is now displayed in an extra tab page in the *web browser*.

### 13.6.2 Access to camera images

Each time the user taps on the LET Automotive logo on the touch screen of the user interface of the Luminoscope® while a headlamp projection is displayed, it simultaneously captures the camera projection and some diagnostic files. These camera images may be useful for future reference.

Starting from the **Advanced** screen.

1. Click on the **Camera images** link 3 on the **Advanced** screen to access the **Camera images** screen.

The following screen is now displayed.




Figure 173: **Camera images** screen

2. Tap on the **Load files list** button 8.

The following screen is displayed:




Figure 174: **Camera images** screen with all available camera images

The screen shows a list of all available camera images. Each entry shows the date and time and the file size.

3. Click on the **Download** link 9 to download the camera image. Alternatively tap on the camera image name to open the camera image.

The camera image is now displayed in an extra tab page in the *web browser*.


### 13.6.3 Access to screenshots

Each time the user taps on the LET Automotive logo on the touch screen, a screenshot of the current user interface of the Luminoscope® is captured simultaneously with some diagnostic files. These screenshots may be useful for future reference.

Starting from the **Advanced** screen.


1. Click on the **Screenshots** link 4 on the **Web interface main** screen.

The following screen is now displayed:

Figure 175: **Screenshots** screen

2. Tap on the **Load files list** button 10.

The following screen is displayed:

Figure 176: **Screenshots** screen with all available screenshots

The screen displays a list of all available screenshots. Each entry shows the date and time and the file size.

3. Click on the **Download** link 11 to download the screenshot. Alternatively tap on the screenshot name to open the screenshot.  
The selected screenshot is now displayed in an extra tab page in the *web browser*.

### 13.6.4 Access to remote Luminoscope® screen

Starting from the **Advanced** screen.

1. Click on the **Remote** link 5 on the **Advanced** screen to open an extra tab page in the *web browser* showing a duplicate of the Luminoscope® screen.

The following screen is now displayed:




Figure 177: **Remote Luminoscope** screen

The Luminoscope® can now be remotely controlled.

2. Close the **Remote control** tab page to terminate the remote view.



## 14 Personal notes

[illegible]

